


TECHNICAL MANUAL

ORGANIZATIONAL MAINTENANCE MANUAL INCLUDING REPAIR PARTS AND SPECIAL TOOLS LIST)



| | |
|---|---------|
| EQUIPMENT DESCRIPTION AND DATA | 1-2 |
| PREVENTIVE MAINTENANCE CHECKS AND SERVICES (PMCS) | 2-1 |
| FUNCTIONAL TESTING | 2-3 |
| TROUBLESHOOTING | 2-10 |
| MAINTENANCE PROCEDURES FOR M14 PROTECTIVE ENTRANCE | 2-50 |
| MAINTENANCE PROCEDURES FOR M59 GAS-PARTICULATE FILTER UNIT | 2-62 |
| MAINTENANCE PROCEDURES FOR M265 INSTALLATION KIT | 2-83 |
| MAINTENANCE ALLOCATION CHART | B-1 |
| REPAIR PARTS AND SPECIAL TOOLS LIST | C-1 |
| EXPENDABLE SUPPLIES AND MATERIALS LIST | D-1 |
| ILLUSTRATED LIST OF MANUFACTURED ITEMS | E-1 |
| ALPHABETICAL INDEX | Index 1 |

COLLECTIVE PROTECTION EQUIPMENT, GUIDED MISSILE SYSTEM, PATRIOT CONSISTING OF

ENTRANCE, PROTECTIVE, PRESSURIZED, COLLAPSIBLE, M14

(NSN 4240-01-105-5521);

FILTER UNIT, GAS-PARTICULATE, 400 CFM, 208 V, 400 Hz, M59

(NSN 4240-00-237-0223);

AND

INSTALLATION KIT, CBR, PROTECTIVE EQUIPMENT, PATRIOT M265

(NSN 4240-01-110-7617)

HEADQUARTERS, DEPARTMENT OF THE ARMY

30 NOVEMBER 1982

WARNINGS

High voltage is used to power this equipment. Before removing or installing power cable, be sure that POWER switch on compartment control module is set to OFF position and that the collective protection equipment power source is shut down to avoid personal injury or loss of life.

If filter unit is operating, high voltage is present at the 208V indicator socket on the power distribution unit. Personal injury or loss of life may result if socket is contacted.

Do not remove covers to service components after toxic exposure without observing proper handling procedures.

Filter seals must be properly seated to prevent bypass of contaminated air:

- Torque access cover bolts 180 to 200 inch-pounds to seat gas filter.
- Tighten inner cover retaining bar until sleeve is flush with top surface to seat particulate filter.

TECHNICAL MANUAL

TM 3-4240-285-20&P

HEADQUARTERS
DEPARTMENT OF THE ARMY
Washington, DC 30 November 1982

Organizational Maintenance Manual
(Including Repair Parts and Special Tools List)
**COLLECTIVE PROTECTION EQUIPMENT,
GUIDED MISSILE SYSTEM, PATRIOT
CONSISTING OF
ENTRANCE, PROTECTIVE, PRESSURIZED, COLLAPSIBLE, M14
(NSN 4240-01-105-5521);
FILTER UNIT, GAS-PARTICULATE, 400 CFM, 208 V, 400 Hz, M59
(NSN 4240-00-237-0223);
AND
INSTALLATION KIT, CBR, PROTECTIVE EQUIPMENT, PATRIOT, M265
(NSN 4240-01-110-7617)**

Current as of August 1982


REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2 located in the back of this manual direct to: Commander, US Army Armament Materiel Readiness Command, ATTN: DRSAR-MAS-C, Aberdeen Proving Ground, MD 21010. A reply will be furnished to you.

| | | Page |
|------------------|--------------------------------------|-------------|
| CHAPTER 1 | INTRODUCTION | 1-1 |
| Section I | General Information | 1-1 |
| Section II | Equipment Description and Data | 1-2 |
| Section III | Principles of Operation | 1-7 |

| | | |
|-------------------|--|---------------------------|
| CHAPTER 2 | MAINTENANCE INSTRUCTIONS | Page 2-1 |
| Section I | Repair Parts, Special Tools, TMDE, and Support Equipment | 2-1 |
| Section II | Service Upon Receipt | 2-1 |
| Section III | Preventive Maintenance Checks and Services (PMCS) | 2-1 |
| Section IV | Functional Testing | 2-3 |
| Section V | Troubleshooting | 2-10 |
| Section VI | Maintenance Procedures for M14 Protective Entrance | 2-50 |
| Section VII | Maintenance Procedures for M59 Gas-Particulate Filter Unit | 2-62 |
| Section VIII | Maintenance Procedures for M265 Installation Kit | 2-83 |
| APPENDIX A | REFERENCES | A-1 |
| APPENDIX B | MAINTENANCE ALLOCATION CHART (MAC) | B-1 |
| APPENDIX C | REPAIR PARTS AND SPECIAL TOOLS LIST | C-1 |

| | | | |
|-------------------|--|----------------|---------------------------|
| | | Page | Illust. Figure |
| Section I | Introduction | C-1 | |
| Section II | Repair Parts List | C-6 | |
| Group 0100 | M14 Protective Entrance | C-6 | C-1 |
| | 0110 Protective Entrance Control Module | C-8 | C-2 |
| Group 0200 | M59 Gas-Particulate Filter Unit | C-10 | C-3 |
| | 0210 Housing Unit | C-12 | C-4 |
| | 0212 Airflow Valve | C-14 | C-5 |
| | 0221 Power Distribution Panel | C-16 | C-6 |
| | 0230 Compartment Control Module | C-18 | C-7 |
| Group 0300 | M265 Installation Kit | C-20 | C-8 |
| Group 0500 | Bulk Supplies | C-22 | |
| Section III | Special Tools and Equipment List (Not applicable)..... | C-23 | |
| Section IV | National Stock Number and Part Number Index | C-23 | |
| APPENDIX D | EXPENDABLE SUPPLIES AND MATERIALS LIST | D-1 | |
| APPENDIX E | ILLUSTRATED LIST OF MANUFACTURED ITEMS | E-1 | |
| | ALPHABETICAL INDEX | Index 1 | |



CHAPTER 1 INTRODUCTION

Section I. GENERAL INFORMATION

1-1. SCOPE.

- a. *Type of Manual:* Organizational maintenance, including the repair parts and special tools list.
- b. *Model Numbers and Equipment Names:*
 - M14 protective entrance —
Protective entrance control module
 - M59 gas-particulate filter unit —
Housing unit
Airflow valve
Power distribution unit
Compartment control module
 - M265 installation kit
- c. *Purpose of Equipment.* Provides filtered air under positive pressure to field shelters.

| <i>Common Name</i> | <i>Official Nomenclature</i> |
|---------------------------------|---|
| M59 gas-particulate filter unit | Filter Unit, Gas-Particulate, 400 CFM, 208 V, 400 Hz, M59 |
| M265 Installation kit | Installation Kit, M265 |
| Cable C5-19-6162-20 | Cable Assembly, Special Purpose Electrical, C5-19-6162-20 |
| Cable C5-19-6170-10 | Cable Assembly, Special Purpose Electrical, C5-19-6170-10 |

1-2. MAINTENANCE FORMS, RECORDS, AND REPORTS.

Department of the Army forms and procedures used for equipment maintenance will be those prescribed by TM 38-750, The Army Maintenance Management System (TAMMS).

| | |
|---------------------|--|
| Cable C5-19-6712 | Cable Assembly, Special Purpose Electrical, C5-19-6712 |
|---------------------|--|

1-3. DESTRUCTION OF MATERIEL TO PREVENT ENEMY USE.

Refer to TM 43-0002-31, Destruction of Chemical Weapons and Defense Equipment to Prevent Enemy Use.

| | |
|--------------|---|
| Cable W90 | Cable Assembly, Special Purpose Electrical, W90 |
|--------------|---|

1-4. PREPARATION FOR STORAGE OR SHIPMENT.

Refer to TM 740-90-1 for administrative storage instructions.

1-5. NOMENCLATURE CROSS-REFERENCE LIST.

Nomenclature cross-references used in this manual includes:

| <i>Common Name</i> | <i>Official Nomenclature</i> |
|-------------------------|---|
| M14 protective entrance | Entrance, Protective, Pressurized, Collapsible, M14 |

- 1-6. **REPORTING EQUIPMENT IMPROVEMENT RECOMMENDATIONS (EIR).** If your collective protection equipment needs improvement, let us know. Send us an EIR. You, the user, are the only one who can tell us what you don't like about your equipment. Let us know why you don't like the design. Put it on an SF 368 (Quality Deficiency Report). Mail it to us at Commander, US Army Armament Materiel Readiness Command, ATTN: DRSAR-MAY-MA, Aberdeen Proving Ground, MD 21010. We'll send you a reply.

Section II EQUIPMENT DESCRIPTION AND DATA

1-7. EQUIPMENT CHARACTERISTICS, CAPABILITIES, AND FEATURES.

Characteristics

- Collective protection equipment (CPE) allows operation in a chemical/biological agent contaminated zone.
- The filter unit provides filtered air under positive pressure to the M14 protective entrance and to the PATRIOT shelter
- Positive pressure prevents dangerous amounts of chemical and biological (CB) agents from entering the protected area
- The M14 protective entrance, while under positive pressure, allows personnel to enter or leave without loss of positive pressure protection in the PATRIOT shelter.

Capabilities and Features

- Both the M14 protective entrance and the PATRIOT Shelter utilize control modules.
- Major components of the CPE may be attached or detached from the PATRIOT shelter without affecting the shelter operation.
- Modular design of CPE permits:
 - a. Easy access to the major components for servicing and maintenance.
 - b. Quick replacement of malfunctioning components.

1-8. LOCATION AND DESCRIPTION OF MAJOR COMPONENTS.

- (A)** PROTECTIVE ENTRANCE. Consists of:
- Shell assembly, which is in two halves, forms the roof and floor.
 - Door assembly, when fully extended, provides access to the protective entrance. The door frame supports the front of the protec-

tive entrance.

- Two support assemblies, when fully extended, form rigid poles between the roof and the floor of the shell assembly. The support assemblies are located at the rear of the protective entrance.
- An impermeable fabric assembly attaches to the two halves of the shell assembly. When the fabric is fully extended, it forms the protective entrance walls.

(B) PROTECTIVE ENTRANCE CONTROL MODULE. Mounted in the roof of the shell assembly, provides white/or black-out red light, purge timing and low pressure warning for the protective entrance.

(C) GAS-PARTICULATE FILTER UNIT. The filter unit housing contains the main fan, gas filters and particulate filters. Inner and outer access covers permit changing the filters.


- The airflow valve, attached to the outside of the filter unit housing, controls the airflow between the filter unit, the shelter, and the protective entrance.

(D) COMPARTMENT CONTROL MODULE. Mounts inside the shelter and contains controls and indicators to operate the collective protection equipment

(E) POWER DISTRIBUTION UNIT. Mounts on the outside of the shelter at the filter unit. It serves as the electrical power distribution center for the collective protection equipment.

(F) AIRDUCT HOSE. Large diameter (6 in.) impermeable fabric hose, in 6 foot sections, connects filter unit, shelter, and protective entrance for filtered air circulation.

(G) SPECIAL PURPOSE ELECTRICAL CABLES. Five cables route electrical power and operating signals between the filter unit, power distribution unit, compartment control module, and protective entrance. (All cables are not shown)



MAJOR COMPONENTS

1-9. IDENTIFICATION, INSTRUCTION, AND WARNING PLATES.

OPENING PROCEDURES

- 1 REMOVE CAP AND ATTACH AIR HOSE
- 2 DISENGAGE LATCHES - RAISE TOP TO FULL HEIGHT
- 3 OPEN DOOR, INSERT DETENT PINS IN DOOR FRAME (OPENING INSTRUCTIONS CONTINUED ON PE WALL)

CLOSING PROCEDURES

- 7 LOWER SIDE - TUCK IN ALL FABRIC - LOWER BACK SIDE
- 8 CHECK FOR FABRIC AND SHELL ALIGNMENT - SECURE LATCHES
- 9 REMOVE AIR HOSE - REPLACE CAP

ENTRANCE PROTECTIVE PRESSURIZED
COLLAPSIBLE, M14

NSN
SERIAL NO
CONT NO US



CAUTION
DO NOT ENTER WHEN
PROTECTIVE ENTRANCE
IS OCCUPIED

AIRFLOW VALVE

NSN
SERIAL NO
CONT NO US

PURGE
INSTRUCTIONS
ROTATE TIMER KNOB
TO 5 (5 MINUTES) PURGE
INDICATOR WILL COME ON
WHEN PURGE INDICATOR
GOES OUT PURGE CYCLE
IS COMPLETE

NO STEP




ERECT PROCEDURES

- 4 ERECT REAR SUPPORTS - ENGAGE WITH POSTS IN TOP
- 5 PULL DETENT PINS HOLDING BRACES AND INSERT THRU SUPPORT JOINTS
- 6 LOWER BRACES INTO BRACKETS - INSERT DETENT PINS
- 7 PULL INTERFACE FABRIC OUTWARD AND STRAIGHTEN
- 8 ALIGN PROTECTIVE ENTRANCE INTERFACE WITH SHELTER CHANNEL
- 9 INSERT INTERFACE INTO CHANNEL (DEPTH INDICATED BY ARROW--HEADS) - SECURE WITH SCREWS
- 10 REMOVE A SIDEWALL CAP AND INSTALL AIR HOSE IF NEEDED FOR RECIRCULATION
- 11 CONNECT ELECTRICAL CABLE

STRIKE PROCEDURES

- 1 DISCONNECT ELECTRICAL CABLE AND RECIRCULATION AIR HOSE
- 2 REPLACE CAPS OVER AIR OPENING AND ELECTRICAL CONNECTOR
- 3 LOOSEN SCREWS SECURING INTERFACE - REMOVE PROTECTIVE ENTRANCE FROM SHELTER - PUSH INTERFACE INSIDE FLUSH TO WALL
- 4 CLEAN FLOOR AREA - CLOSE AND LATCH DOOR
- 5 SUPPORT TOP - RAISE BRACES AND SECURE TO REAR SUPPORTS USING DETENT PINS FROM SUPPORT JOINTS - FOLD AND SECURE TO FLOOR WITH STRAPS
- 6 SUPPORT TOP (FRONT AND BACK) - REMOVE DETENT PINS FROM DOOR FRAME
- 6 PUSH DOOR IN AT CENTER - LOWER TOP LEVEL SLOWLY TO 2" HIGH - INTERFACE MUST FORM ACCORDIAN FOLD (CLOSING INSTRUCTIONS CONTINUED ON TOP OF P E)



1-10. EQUIPMENT DATA.

Dimensions and Weights of Collective Protection Equipment Components

| Component | Length | | Width | | Height | | Weight | |
|---|-----------|--------|-----------|--------|--------|--------|--------|-------|
| | Inch | CM | Inch | CM | Inch | CM | LB | Kg |
| M14 protective entrance packaged dimensions erected dimensions | 49.3 | 125.22 | 43.3 | 109.98 | 12.5 | 31.75 | 145 | 65.8 |
| | 49.3 | 125.22 | 43.3 | 109.98 | 85.4 | 216.91 | 145 | 65.8 |
| Protective entrance control module | 16 | 40.64 | 6.75 | 17.14 | 5 | 12.70 | 7.5 | 3.40 |
| M59 gas-particulate filter unit | 34 | 86.4 | 36 | 91.40 | 32 | 81.30 | 256 | 116.1 |
| Compartment control module | 7.7 | 19.55 | 11.75 | 29.84 | 6.5 | 16.51 | 9 | 4.09 |
| Power distribution unit | 18.5 | 46.99 | 8.25 | 20.95 | 4.25 | 10.79 | 16 | 7.26 |
| | Outer Dia | | Inner Dia | | 10 | 25.40 | 7.8 | 3.54 |
| Particulate filter (each) | 16.6 | 42.16 | 12 | 30.48 | | | | |
| | Outer Dia | | Inner Dia | | | | | |
| Gas filter (each) | 21.4 | 54.35 | 16.7 | 42.41 | 10 | 25.40 | 37.8 | 17.1 |


Operating Power Requirements and Characteristics of Collective Protection Equipment Components

| Component | Power Requirements | Input Voltage | Maximum Capacity | Airflow (cfm) |
|------------------------------------|----------------------|------------------------|------------------|---------------------------|
| Protective entrance control module | 2 amp at 28 V dc | 28 V dc | 3.5 kW | 400 maximum |
| M59 gas-particulate filter unit | 1700 Watts | 208 V, 400 Hz, 3-phase | | |
| Airflow valve | 1 amp max at 28 V dc | | | 40 minimum at 20.0 in. wg |
| Power distribution unit | | 208 V, 400 Hz, 3-phase | | |
| Compartment control module | 1 amp max at 28 V dc | 28 V dc | | |
| Particulate filters | | | | 400 |
| Gas filters | | | | 400 |

Section III PRINCIPLES OF OPERATION

I-11. AIR FILTERING AND PRESSURIZATION SYSTEM.

- a. The M59 gas-particulate filter unit removes toxic gases and dust from the air supplied to the shelter and M14 protective entrance. The fan draws outside air through the air inlet and forces it into the filter unit. The fan forces filtered air from the filter unit to the airflow valve. The airflow valve directs filtered air to the shelter and M14 protective entrance. Airduct hoses deliver filtered air to the M14 protective entrance. Filtered air enters the shelter through the air conditioner. Pressure sensing components in the compartment control module automatically adjust the airflow valve to maintain a positive pressure in the shelter.
- b. The M14 protective entrance provides a pressurized transition area between the shelter and the outside contaminated zone. Personnel entering from the outside must wait five minutes within the protective entrance before entering the shelter. The flow of the filtered air purges contamination from the M14 protective entrance. The protective entrance control module contains the purge timer and a low-pressure warning indicator.



CHAPTER 2 MAINTENANCE INSTRUCTIONS

Section I. REPAIR PARTS, SPECIAL TOOLS, TMDE, AND SUPPORT EQUIPMENT

- 2-1. COMMON TOOLS AND EQUIPMENT.** For authorized common tools and equipment, refer to the modified table of organization and equipment (MTOE) applicable to your unit
- 2.2 SPECIAL TOOLS, TMDE, AND SUPPORT EQUIPMENT.** No special tools, TMDE, or support equipment are required.
- 2.3 REPAIR PARTS.** Repair parts are listed and illustrated in Appendix C of this manual

Section II. SERVICE UPON RECEIPT

- 2.4 SERVICE UPON RECEIPT.** Refer to the following operator's and organizational maintenance manuals as appropriate:
- | | |
|---------------------|----------------------------------|
| *TM 9-1430-600-12-1 | Engagement Control Station |
| *TM 9-1430-602-12-1 | Information Coordination Central |
| *TM 9-1430-604-12-1 | Communication Relay Group |

Section III. PREVENTIVE MAINTENANCE CHECKS AND SERVICES (PMCS)

- 2.5 PMCS PROCEDURES.**
- a. *General.* The PMCS procedures are contained in following table. They are arranged in logical sequence requiring a minimum amount of time and motion on the part of the persons performing them and are arranged so that there will be a minimum interference between persons performing checks simultaneously on the same end item.
 - b. *Item Number Column.* Checks and services are numbered in chronological order regardless of interval. This column shall be used as a source of item numbers of the "TM Number" column on DA Form 2404, Equipment Inspection and Maintenance Worksheet, in recording results of PMCS.
 - c. *Item To Be Inspected Column.* The items listed in this column are divided into groups indicating the portion of the equipment of which they are a part, for example, "Filter Unit," "Protective Entrance." Under these groupings, the items to be inspected are identified by as few words, usually the common name, as will clearly identify the item, for example, "main fan assembly," "airflow valve."
 - d. *Procedures Column.* This column contains a brief description of the procedure by which the check is to be performed. It contains all the information required to accomplish the checks and services, including appropriate tolerances, adjustment limits, and instrument and gage readings

* To be published

PREVENTIVE MAINTENANCE CHECKS AND SERVICES (PMCS) SEMIANNUAL SCHEDULE

NOTE

Perform checks and services in the order listed before you perform functional testing.

| Item No | Item To Be Inspected | Procedures |
|---------|---|--|
| 1 | <u>M59 gas-particulate filter unit</u> | |
| | Filter housing outside surfaces | <p>Inspect identification and instruction plates. You must be able to read them. Replace plates if necessary (p. 2-65 and 2-66).</p> <p>Inspect outside surfaces for rust, chipped paint, or bare metal on painted surfaces. Repaint or touchup as necessary (p. 2-65).</p> <p>Make sure that all parts are secure and that there is no loose or missing hardware. Tighten loose hardware. Replace missing hardware.</p> |
| | Main fan assembly cable | Inspect cable assembly for bare wires, broken insulation, broken or damaged connector. Replace damaged main fan assembly (p. 2-74). |
| | Airflow valve | Inspect valve for damage and loose mounting hardware. Replace missing mounting hardware. Replace damaged airflow valve (p. 2-76). |
| | Power distribution unit | <p>Inspect unit for loose or missing mounting hardware. Tighten loose hardware. Replace missing hardware.</p> <p>Inspect for damage or missing electrical covers. Replace power distribution unit if the covers are damaged or missing (p. 2-79).</p> |
| | Gas-particulate filters | <p>Remove filters (p. 2-68) and check for physical or water damage.</p> <p>Inspect housing seal and inner cover gasket for damage. Replace seal or gasket if unserviceable (p. 2-69). Reinstall filters or install new filters (p. 2-70).</p> |
| 2 | <u>M265 installation kit</u> | |
| | Special purpose electrical cable assemblies | Inspect cable assemblies for bare wires, broken insulation, broken or damaged connectors. Replace damaged cable assemblies (p. 2-83 through 2-95). |
| | Air duct hoses | Inspect air duct hoses for damage or missing clamps. Repair or replace air duct hoses if necessary (p. 2-96). Replace missing clamps. |

| Item No | Item To Be Inspected | Procedures |
|---------|--|---|
| 3 | <u>M14 protective entrance</u> | <p>Inspect identification and instruction plates. You must be able to read them. Replace plates if necessary (p. 2-51).</p> <p>Inspect outside surface for chipped paint or bare metal on painted surfaces. Repaint or touchup as necessary (p. 2-56).</p> <p>Make sure that all parts are secure and that there is no loose or missing hardware. Tighten loose hardware (p. 2-50). Replace missing hardware.</p> |
| 4 | <u>Collective protection equipment</u> | <p>Perform functional testing (p. 2-3 through p. 2-9).</p> |

Section IV. FUNCTIONAL TESTING

- 2-6. GENERAL.** This section contains instructions for functional testing the collective protection equipment for shelter. These tests must be performed following installation of the equipment, and semiannually thereafter.
- a. *Preventive Maintenance Checks and Services (PMCS).* Perform PMCS on page 2-1 before performing functional testing.
 - b. *Troubleshooting Procedures.* Refer to troubleshooting on page 2-10 for malfunctions and corrections.

2-7. FUNCTIONAL TEST.

| LOCATION | ITEM | ACTION | INDICATION/REMARKS |
|----------|------|--------|--------------------|
|----------|------|--------|--------------------|

Power
Circuit

Cables

Check that all connections are
tight

Connector J6 on power
distribution unit is not used.



Power source

Check that power is supplied
to power distribution unit.

Power
Distribution
Unit (PDU)

Circuit breakers

Check that circuit breakers
(1, 2, 3, and 4) are set.
Press to set




PDU

Compartment
Control
Module (CCM)

Circuit breakers

Set POWER switch (14)
to OFF

Check that circuit breakers
(5, 6, 7, and 8) are set.
Press to set




CCM

Indicator lights

Press to test lamps
MASK (9)

Light will flash and warning horn
(10) will sound. Replace lamp if
necessary (p 2-82)



ENTRANCE LOW PRESSURE
(11)



CHANGE FILTER (12)

OCCUPIED (13)

Light will light when pressed.
Replace lamp if necessary
(p 2-82)

Light will light when pressed.
Replace lamp if necessary
(p. 2-82)


Light will light when pressed
Replace lamp if necessary
(p. 2-82)

| LOCATION | ITEM | ACTION | INDICATION/REMARKS |
|---|---|---|---|
| Protective Entrance Control Module (PECM) | Indicator lights | Press to test lamps LOW PRESSURE (15) | Light will light when pressed. Replace lamp if necessary (p 2-60) |
| | | PURGE (16) | Light will light when pressed. Replace lamp if necessary (p. 2-59) |
| |  | | |
| | Dome light | Set dome light switch (17) to WHITE. | Dome light (18) will show white light. Replace lamp if necessary (p. 2-61). |
| | | Set switch (17) to RED | Dome light (18) will show red light. Replace lamp if necessary (p 2-61) |
| | | Set Switch (17) to OFF | Dome light (18) will go off. |
| | Timer | Rotate TIMER (19) fully clockwise | PURGE light (16) will light. |
| | | | OCCUPIED light in compartment control module will light |
| | | Allow TIMER (19) to return to "0" (approximately five minutes). | PURGE and OCCUPIED lights will go off |
| |  | | |

2-7. FUNCTIONAL TEST (CONT).

| LOCATION | ITEM | ACTION | INDICATION/REMARKS |
|----------|------|--------|--------------------|
|----------|------|--------|--------------------|

| | | | |
|----------------------------------|---------------------|---|--|
| Compartment Control Module | Pressure circuit | Close shelter door and protective entrance door. | |
| | | Set POWER switch (14) to ON | Main fan must start and run MASK indicator light (9) will flash Warning horn (10) will sound until shelter is pressurized (approximately 30 seconds) MASK light (9) will go off and warning horn (10) will silence when proper shelter pressure is reached |
| | | Allow horn to silence automatically This will indicate proper system operation. | |



ENTRANCE LOW PRESSURE light (11) will light when filter unit is started and then go off when proper protective entrance pressure is reached

When loss of power to the collective protection equipment occurs with the compartment control module POWER switch in the ON position, the MASK light (9) will flash and warning horn (10) will sound

| | | | |
|----------------------------------|---------------------|----------------------------|---|
| Compartment Control Module | Pressure circuit | Open shelter door | MASK light (9) will flash. Warning horn (10) will sound |
| | | Press HORN OFF button (20) | Button will stay in pressed position Warning horn will stop sounding. MASK light (9) will light and stay on |

| LOCATION | ITEM | ACTION | INDICATION/REMARKS |
|----------|------|--------|--------------------|
|----------|------|--------|--------------------|

Open protective entrance door



Compartment
Control
Module

Pressure
circuit

ENTRANCE LOW PRESSURE
light (11) will light.

Protective
Entrance
Control
Module

LOW PRESSURE light (15) will
light



Close protective entrance and
shelter doors

Within 30 seconds
ENTRANCE LOW PRES-
SURE light (11) will go off.
Also, the LOW PRESSURE
light (15) on the protective
entrance control module will
go off

MASK light (9) will go off
HORN OFF button (20) will
reset.


Power
Distribution
Unit

CHANGE FILTER
indicator light

Disconnect tubing (21)
(green dot).

Filter unit must be operating.

PDU




2-7. FUNCTIONAL TEST (CONT).

| LOCATION | ITEM | ACTION | INDICATION/REMARKS |
|----------|------|--------|--------------------|
|----------|------|--------|--------------------|

Compartment
Control
Module

CHANGE FILTER
indicator light

CHANGE FILTER light (12)
will light



CCM

Power
Distribution
Unit

Reconnect tubing (21)
(green dot) removed
above
Tighten finger tight

Fan and
Airflow
Valve Housing
Init

Airflow valve

Close shelter and
protective entrance doors

Filter unit must be operating

Loosen hose clamp (22) on
protective cap (23) and remove
cap from outlet port marked TO
PROT ENT

Open shelter and protective
entrance doors

The sliding plate (24) in the
airflow valve must move to
completely close off the outlet
marked TO PROT ENT


Close shelter door

The sliding plate (24) in the
airflow valve will move toward
the port marked TO SHELTER.
This partly opens the port
marked TO PROT ENT

Turn off filter unit
Set compartment control
POWER switch (14) to OFF

Observe that sliding plate (24)
marked TO PROT ENT is
completely open (port marked
TO SHELTER is closed).

Replace protective cap (23)
on port marked TO PROT ENT.
Tighten hose clamp (22).




| LOCATION | ITEM | ACTION | INDICATION/REMARKS |
|----------|------|--------|--------------------|
|----------|------|--------|--------------------|

NOTE

If the following indications are not obtained, the CCM batteries may need charging. Operate the collective protective equipment for one-half hour and then repeat this check. If indications are still not obtained, replace CCM (p 2-81)

| | | | |
|----------------------------------|---------------------------------|------------------------------|-------------------------------|
| Compartment Control Module | Loss of power warning system | Disconnect plug P1 (25) | |
| | | Set POWER switch (14) to ON. | MASK Light (9) will flash. |
| | | | Warning horn (10) will sound. |
| | | Set POWER switch (14) to OFF | |
| | | Reconnect plug P1 (25) | |



Section V TROUBLESHOOTING

2-8. GENERAL.

- a. This section contains troubleshooting information for locating and correcting most of the operating troubles which may develop in your protective equipment. Each malfunction for an individual component, unit, or system is followed by a list of tests or inspections which will help you to determine corrective actions to take. You should perform the test/inspections and corrective actions in the order listed.

- b. This manual cannot list all possible malfunctions that may occur, nor all tests or inspections and corrective actions. If a malfunction is not listed (except when malfunction and cause are obvious) or is not corrected by listed corrective actions, notify your supervisor.

NOTE

When beginning a troubleshooting procedure, be sure power is on at the CCM and the power source.

When measuring voltage at the power distribution unit (PDU), TP #10 is ground.


2-9. TROUBLESHOOTING PROCEDURES.

- a. Perform functional test first. Then, use the symptom index for quick access to the troubleshooting procedures.



SYMPTOM INDEX

| | Troubleshooting Procedure Page |
|---|--------------------------------------|
| 1. MASK light flashing and/or warning horn sounding | 2-11 |
| 2. Protective entrance LOW PRESSURE lights on | 2-21 |
| 3. No power indication (all indicator lights do not illuminate when pressed to test) | 2-27 |
| 4. Protective entrance LOW PRESSURE lights will not come on | 2-33 |
| 5. CHANGE FILTER lights with clean filter | 2-39 |
| 6. CHANGE FILTER light does not illuminate | 2-40 |
| 7. OCCUPIED AND PURGE lights do not operate properly | 2-42 |
| 8. INDICATORS circuit breaker trips | 2-45 |
| 9. Protective entrance dome light does not come on | 2-48 |

- b. The following describes the use of the troubleshooting charts:



1. MASK LIGHT FLASHING AND/OR WARNING HORN SOUNDING.




LEGEND

CCM = Compartment Control Module



1. MASK LIGHT FLASHING AND/OR WARNING HORN SOUNDING (CONT)

Page 2-11





LEGEND


CCM = Compartment Control Module
FU = Filter Unit



Page 2-12





SPECIAL PURPOSE ELECTRICAL CABLE ROUTING DIAGRAM



CCM = Compartment Control Module
PDU = Power Distribution Unit
TP = Test Point

1. MASK LIGHT FLASHING AND/OR WARNING HORN SOUNDING (CONT)



Page
2-13




SPECIAL PURPOSE ELECTRICAL CABLE ROUTING DIAGRAM

LEGEND


CCM = Compartment Control Module
PDU = Power Distribution Unit



MAIN FAN CIRCUIT BREAKER



Page
2-12





LEGEND


CCM = Compartment Control Module
PDU = Power Distribution Unit

1. MASK LIGHT FLASHING AND/OR WARNING HORN SOUNDING (CONT)

Page
2-15



SPECIAL PURPOSE ELECTRICAL CABLE ROUTING DIAGRAM




MULTIMETER

LEGEND


CCM = Compartment Control Module
PDU = Power Distribution Unit
TP = Test Point

Page 2-12 or 2-15




SPECIAL PURPOSE ELECTRICAL CABLE ROUTING DIAGRAM

208V
POWER INDICATOR




LEGEND

CCM = Compartment Control Module
PDU = Power Distribution Unit
TP = Test Point




1. MASK LIGHT FLASHING AND/OR WARNING HORN SOUNDING (CONT).




LEGEND

CCM = Compartment Control Module


PDU = Power Distribution Unit



Page 2-11





SPECIAL PURPOSE ELECTRICAL CABLE ROUTING DIAGRAM



LEGEND

CCM = Compartment Control Module



1. MASK LIGHT FLASHING AND/OR WARNING HORN SOUNDING (CONT).



LEGEND

PDU = Power Distribution Unit

2 PROTECTIVE ENTRANCE LOW PRESSURE LIGHTS ON.



LEGEND


CCM = Compartment Control Module

PDU = Power Distribution Unit




PE = Protective Entrance

PECM = Protective Entrance Control Module

TP = Test Point



2. PROTECTIVE ENTRANCE LOW PRESSURE LIGHTS ON (CONT).






LEGEND

CCM = Compartment Control Module

PDU = Power Distribution Unit

TP = Test Point



Page
2-22




LEGEND

CCM = Compartment Control Module
PDU = Power Distribution Unit
TP = Test Point

2. PROTECTIVE ENTRANCE LOW PRESSURE LIGHTS ON (CONT)

Page
2-21


SPECIAL PURPOSE ELECTRICAL CABLE ROUTING DIAGRAM




MULTIMETER

LEGEND

CCM = Compartment Control Module
PDU = Power Distribution Unit



SPECIAL PURPOSE ELECTRICAL CABLE ROUTING DIAGRAM



MULTIMETER


LEGEND

CCM = Compartment Control Module



PDU = Power Distribution Unit

TP = Test Point

Page 2-24



2. PROTECTIVE ENTRANCE LOW PRESSURE LIGHTS ON (CONT).






LEGEND

CCM = Compartment Control Module

PE = Protective Entrance


3 NO POWER INDICATION (ALL INDICATOR LIGHTS DO NOT ILLUMINATE WHEN PRESSED TO TEST)





MULTIMETER

LEGEND


CCM = Compartment Control Module
 PDU = Power Distribution Unit
 PE = Protective Entrance
 PECM = Protective Entrance Control Module
 TP = Test Point



3. NO POWER INDICATION (ALL INDICATOR LIGHTS DO NOT ILLUMINATE WHEN PRESSED TO TEST) (CONT).



SPECIAL PURPOSE ELECTRICAL CABLE ROUTING DIAGRAM



PDU


MULTIMETER

EGEND



CM = Compartment Control Module

DU = Power Distribution Unit

P = Test Point



SPECIAL PURPOSE ELECTRICAL CABLE ROUTING DIAGRAM





LEGEND

PDU = Power Distribution Unit


TP = Test Point

3. NO POWER INDICATION (ALL INDICATOR LIGHTS DO NOT ILLUMINATE WHEN PRESSED TO TEST) (CONT).

Page
2-29



SPECIAL PURPOSE ELECTRICAL CABLE ROUTING DIAGRAM




LEGEND

PDU = Power Distribution Unit


PECM = Protective Entrance Control Module

TP = Test Point


Page 2-27



SPECIAL PURPOSE ELECTRICAL CABLE ROUTING DIAGRAM



MULTIMETER



LEGEND


CCM = Compartment Control Module

PDU = Power Distribution Unit

TP = Test Point


3 NO POWER INDICATION (ALL INDICATOR LIGHTS DO NOT ILLUMINATE WHEN PRESSED TO TEST) (CONT).

Page
2-31






LEGEND

PDU = Power Distribution Unit



4. PROTECTIVE ENTRANCE LOW PRESSURE LIGHTS WILL NOT COME ON




LEGEND

CCM = Compartment Control Module

PE = Protective Entrance


PECM = Protective Entrance Control Module

4. PROTECTIVE ENTRANCE LOW PRESSURE LIGHTS WILL NOT COME ON (CONT).




LEGEND

PDU = Power Distribution Unit
 PE = Protective Entrance
 PECM = Protective Entrance Control Module
 P = Test Point




MULTIMETER




SPECIAL PURPOSE ELECTRICAL CABLE ROUTING DIAGRAM

Page
2-34





SPECIAL PURPOSE ELECTRICAL CABLE ROUTING DIAGRAM



LEGEND

CCM = Compartment Control Module
PDU = Power Distribution Unit


4. PROTECTIVE ENTRANCE LOW PRESSURE LIGHTS WILL NOT COME ON (CONT).




EGEND

PDU = Power Distribution Unit


CM = Protective Entrance Control Module



SPECIAL PURPOSE ELECTRICAL CABLE ROUTING DIAGRAM




CHANGE FILTER INDICATOR







LEGEND

CCM = Compartment Control Module
 PDU = Power Distribution Unit
 TP = Test Point

5. CHANGE FILTER LIGHTS WITH CLEAN FILTER



6 CHANGE FILTER LIGHT DOES NOT LIGHT.




LEGEND


CCM = Compartment Control Module

PDU = Power Distribution Unit

P = Test Point








SPECIAL PURPOSE ELECTRICAL CABLE ROUTING DIAGRAM




LEGEND

CCM = Compartment Control Module


7. OCCUPIED AND PURGE LIGHTS DO NOT OPERATE PROPERLY.



LEGEND
PDU = Power Distribution Unit
PECM = Protective Entrance Control Module
TP = Test Point





SPECIAL PURPOSE ELECTRICAL CABLE ROUTING DIAGRAM



LEGEND

CCM = Compartment Control Module

7 OCCUPIED AND PURGE LIGHTS DO NOT OPERATE PROPERLY (CONT).





LEGEND



PDU = Power Distribution Unit

PECM = Protective Entrance Control Module

8. INDICATORS CIRCUIT BREAKER TRIPS.



SPECIAL PURPOSE ELECTRICAL CABLE ROUTING DIAGRAM






LEGEND

CCM = Compartment Control Module

PDU = Power Distribution Unit

TP = Test Point

8 INDICATORS CIRCUIT BREAKER TRIPS (CONT)




LEGEND



PDU = Power Distribution Unit

PECM = Protective Entrance Control Module

TP = Test Point






Page
2-46



LEGEND

PDU = Power Distribution Unit
TP = Test Point

9. PROTECTIVE ENTRANCE DOME LIGHT DOES NOT COME ON.




LEGEND

PDU = Power Distribution Unit


PE = Protective Entrance

PECM = Protective Entrance Control Module

TP = Test Point




SPECIAL PURPOSE ELECTRICAL CABLE ROUTING DIAGRAM



PDU

Page 2-48



LEGEND

PDU = Power Distribution Unit

PE = Protective Entrance

PECM = Protective Entrance Control Module

Section VI MAINTENANCE PROCEDURES FOR M14 PROTECTIVE ENTRANCE

2-10. GENERAL. These instructions are for use by organizational maintenance personnel. They apply to:
M14 protective entrance
Protective entrance control module

2-11. M14 PROTECTIVE ENTRANCE - MAINTENANCE INSTRUCTIONS.

This task covers

- | | | | |
|----------------|-----------------|----------------|-------------|
| a. Replacement | c. Removal | e. Disassembly | g. Painting |
| b. Repair | d. Installation | f. Reassembly | |

INITIAL SETUP

Tools

General Mechanics Tool Kit
SC 5180-90-CL-N26

References

*TM 9-1430-600-12-1 Engagement Control Station
*TM 9-1430-602-12-1 Information Coordination Central
*TM 9-1430-604-12-1 Communication Relay Group

| LOCATION | ITEM | ACTION |
|----------|------|--------|
|----------|------|--------|


REPLACEMENT

| | | |
|---------|-------------------------|---|
| PATRIOT | M14 protective entrance | Refer to TM 9-1430-600-12-1, TM 9-1430-602-12-1, or TM 9-1430-604-12-1, for protective entrance replacement instructions. |
|---------|-------------------------|---|

REPAIR

M14 Protective Entrance (PE)

Impermeable wall fabric



Repair tears or slits:

Clean damaged area using rags (item 6, app D) and dry-cleaning solvent (item 4, app D).

Cut a piece of tape (item 7, app D) about four inches longer than the tear or slit. Position tape over the tear or slit and press firmly in place.

Apply tape to the inside of the protective entrance impermeable fabric wall. If necessary for added strength, crossed strips of tape may be used

| LOCATION | ITEM | ACTION |
|----------|------|--------|
|----------|------|--------|


REMOVAL

M14 Protective
Entrance

Instruction plates (1, 2,
and 4) and identification
plate (3)

Pick up edge of plate with sharp tool.

Pull plate completely off the mounting surface



OPENING PROCEDURES

- 1 REMOVE CAP AND ATTACH AIR HOSE
- 2 DISENGAGE LATCHES - RAISE TOP TO FULL HEIGHT
3. OPEN DOOR, INSERT DETENT PINS IN DOOR FRAME, (OPENING INSTRUCTIONS CONTINUED ON P E WALL)

CLOSING PROCEDURES

- 7 LOWER DOOR SIDE - TUCK IN ALL FABRIC - LOWER BACK SIDE
- 8 CHECK FOR FABRIC AND SHELL ALIGNMENT - SECURE LATCHES
- 9 REMOVE AIR HOSE - REPLACE CAP

ENTRANCE, PROTECTIVE PRESSURIZED
COLLAPSIBLE M14

NSN
SERIAL NO
CONT NO US

CAUTION
DO NOT ENTER WHEN
PROTECTIVE ENTRANCE
IS OCCUPIED

2-11. M14 PROTECTIVE ENTRANCE - MAINTENANCE INSTRUCTIONS (CONT).

LOCATION

ITEM

ACTION


INSTALLATION

Instruction plates (1, 2, and 4) and identification plate (3)

Thoroughly clean mounting surface with dry-cleaning solvent (item 4, app D). Surface must be free of all contamination such as oil, grease, dirt, or any foreign matter

Peel back paper from adhesive back of instruction or identification plate.

Mount plate and apply pressure to plate surface

**OPENING PROCEDURES**

- 1 REMOVE CAP AND ATTACH AIR HOSE
- 2 DISENGAGE LATCHES - RAISE TOP TO FULL HEIGHT
- 3 OPEN DOOR, INSERT DETENT PINS IN DOOR FRAME, (OPENING INSTRUCTIONS CONTINUED ON P E WALL)

CLOSING PROCEDURES

- 7 LOWER DOOR SIDE - TUCK IN ALL FABRIC - LOWER BACK SIDE
- 8 CHECK FOR FABRIC AND SHELL ALIGNMENT - SECURE LATCHES
- 9 REMOVE AIR HOSE - REPLACE CAP

ENTRANCE, PROTECTIVE PRESSURIZED COLLAPSIBLE M14

NSN
SERIAL NO
CONT NO US

CAUTION
DO NOT ENTER WHEN
PROTECTIVE ENTRANCE
IS OCCUPIED

| LOCATION | ITEM | ACTION |
|----------|------|--------|
|----------|------|--------|

REMOVAL

M14 Protective Entrance
Airduct Inlet


Dust and moisture seal
protective cap

Loosen hose clamp (1) Remove airduct hose (2) from
inlet (3)

Reach through inlet and hold nut (4) with wrench.

Remove screw (5) from nut (4), washer (6), and cable
loop on cap (7) from inlet (3)

Remove cap (7) from protective entrance (8)



M14 Protective
Entrance Airduct
Outlet


Dust and moisture seal
protective cap

Loosen hose clamp (9) Remove protective cap (10) from
outlet (11)

Hold screw (12) with a wrench

From inside PE, unscrew nut (13) and remove washer
(14)

Remove screw (12), washer (15) and cable loop on cap (10)
from protective entrance



2-11. M14 PROTECTIVE ENTRANCE - MAINTENANCE INSTRUCTIONS (CONT).


| LOCATION | ITEM | ACTION |
|----------|------|--------|
|----------|------|--------|

DISASSEMBLY

Dust and moisture seal
protective cap

Unscrew nut (1). Remove washer (2), screw (3), support
cable (4), and washer (5) from rubber cap (6).

Unscrew adjustment screw on hose clamp (7) and
remove from rubber cap (6).



REPAIR

Support cable

Fabricate support cable (fig E-1, app E)

REASSEMBLY

Dust and moisture seal
protective cap

Install hose clamp (7) in groove in rubber cap (6). Turn
adjustment screw just enough to keep clamp in place.

Secure support cable (4) to rubber cap (6) with screw (3),
washer (5), washer (2), and nut (1).

| LOCATION | ITEM | ACTION |
|----------|------|--------|
|----------|------|--------|

INSTALLATION

M14 Protective
Entrance Airduct Inlet


Dust and moisture seal
protective cap

Place screw (5) through washer (6), support cable loop and
hole at base of airduct inlet (3).

Reach through airduct inlet and install nut (4)
Tighten securely

Place airduct hose (2) on airduct inlet (3).

Tighten hose clamp (1) securely.



M14 Protective
Entrance Airduct Outlet


Dust and moisture seal
protective cap

Install screw (12) and washer (15) with support cable loop

From inside PE, install washer (14) and nut (13)
on screw (12). Tighten securely.

Place protective cap (10) on airduct outlet (11).

Tighten hose clamp (9) securely.



2-11. M14 PROTECTIVE ENTRANCE - MAINTENANCE INSTRUCTIONS (CONT).


| LOCATION | ITEM | ACTION |
|----------|------|--------|
|----------|------|--------|

DISASSEMBLY

Dust and moisture seal
protective cap

Unscrew nut (1) Remove washer (2), screw (3), support
cable (4), and washer (5) from rubber cap (6).

Unscrew adjustment screw on hose clamp (7) and
remove from rubber cap (6).



REPAIR

Support cable

Fabricate support cable (fig E-1, app E).

REASSEMBLY

Dust and moisture seal
protective cap

Install hose clamp (7) in groove in rubber cap (6). Turn
adjustment screw just enough to keep clamp in place.

Secure support cable (4) to rubber cap (6) with screw (3),
washer (5), washer (2), and nut (1).

| LOCATION | ITEM | ACTION |
|----------|------|--------|
|----------|------|--------|

INSTALLATION

M14 Protective
Entrance Airduct Inlet


Dust and moisture seal
protective cap

Place screw (5) through washer (6), support cable loop and
hole at base of airduct inlet (3).

Reach through airduct inlet and install nut (4)
Tighten securely

Place airduct hose (2) on airduct inlet (3)

Tighten hose clamp (1) securely.



M14 Protective
Entrance Airduct Outlet


Dust and moisture seal
protective cap

Install screw (12) and washer (15) with support cable loop

From inside PE, install washer (14) and nut (13)
on screw (12). Tighten securely.

Place protective cap (10) on airduct outlet (11).

Tighten hose clamp (9) securely.



2-12. M14 PROTECTIVE ENTRANCE CONTROL MODULE - MAINTENANCE INSTRUCTIONS (CONT).

| LOCATION | ITEM | ACTION |
|----------|------|--------|
|----------|------|--------|

REMOVAL (CONT)

M14 Protective Entrance

Protective entrance control module

Disconnect adapter (6) on hose (7) from adapter (8)


Remove screws (9) and washers (10)

Remove protective entrance control module (11) from inside the protective entrance

CAUTION

Hold coupling on protective entrance control module with a wrench to prevent it from turning

Disconnect adapter (12) on hose (7) from adapter (13) on protective entrance control module.

**REPAIR**

Hose

Fabricate replacement hose (7) (fig E-3A, app E). Cut adapters (6 and 12) from hose and insert adapters in new hose.

INSTALLATION

M14 Protective Entrance

Protective entrance control module

Install hose on protective entrance control module. Hold adapter (13) with a wrench and tighten adapter (12).

Position protective entrance control module (11) against brackets (14) in protective entrance.


Install screws (9) thru washers (10) and into brackets (14). Tighten securely.

Install adapter (6) on adapter (8) and tighten.

Install electrical cable connector J20 (5) with preformed packing (4) in protective entrance from the inside.

From the outside, install loop of connector cover (3) and nut (2) on electrical cable connector J20 (5). Tighten nut securely.

Reconnect electrical cable plug P20.




| LOCATION | ITEM | ACTION |
|----------|------|--------|
|----------|------|--------|

REMOVAL

Protective Entrance
Control Module

Knob

Pull knob (1) from timer shaft (2)



INSTALLATION


Align knob pointer with 0 on panel.
Push knob (1) on timer shaft (2).

REMOVAL

Protective Entrance
Control Module

PURGE Indicator
lamp

Unscrew Indicator light (3) from Indicator light base (4).
Pull out lamp (5) from Indicator light (3).



INSTALLATION

Insert indicator lamp (5) in indicator light (3).

Install indicator light (3) in light base (4).

2-12. M14 PROTECTIVE ENTRANCE CONTROL MODULE - MAINTENANCE INSTRUCTIONS (CONT).

| LOCATION | ITEM | ACTION |
|----------|------|--------|
|----------|------|--------|


REMOVAL

Protective Entrance Control Module

LOW PRESSURE lamp

Using two screwdrivers, gently pry lens (1) from panel (2)

Remove lamps (3) from lens (1)



DETAIL A

INSTALLATION

Insert lamps (3) in lens (1) Insert lens (1) into panel (2) as shown in detail A Press lens into panel until it snaps into place



REMOVAL

Protective Entrance Control Module

Identification plate

Lift edge of plate (4) with a sharp tool.

Pull plate completely off the mounting surface.



INSTALLATION

Thoroughly clean mounting surface with dry-cleaning solvent (item 4, app D) Mounting surface must be free of all contamination such as oil, grease, dirt, or any foreign matter.

Peel back adhesive paper from plate back.

Mount the plate and apply pressure to the plate surface.

| LOCATION | ITEM | ACTION |
|---|------|--|
| <div>DISASSEMBLY</div> <div> <div>Protective Entrance Control Module</div> <div>Dome light</div> </div> | | |
| | | <p>Remove screws (1), retainer (2), light lens (3) and dome light gasket (4).</p> <p>Remove red lamp (5) by pressing in on the bulb and rotating it counterclockwise. Pull red lamp from socket (6).</p> <p>Remove clear lamp (7) by pressing in on the bulb and rotating it counterclockwise. Pull clear lamp from socket (8).</p> |
| <div>REPAIR</div> <div> <div>Protective Entrance Control Module</div> <div>Dome light</div> </div> | | |
| | | <p>Lamps, screws, lens, and dome light gasket</p> <p>Replace if unserviceable.</p> |
| <div>REASSEMBLY</div> <div> <div>Protective Entrance Control Module</div> <div>Dome light</div> </div> | | |
| | | <p>Insert red lamp (5) in socket (6). Aline studs in lamp base with slot in socket. Press in and turn red lamp clockwise until it locks in place.</p> <p>Insert clear lamp (7) in socket (8). Aline studs in lamp base with slot in socket. Press in and turn clear lamp clockwise until it locks in place.</p> <p>Place gasket (4) on dome light lens (3).</p> <p>Place retainer (2) on gasket and aline screw holes.</p> <p>Position assembly in place and install screws (1). Tighten securely.</p> |

Section VII MAINTENANCE PROCEDURES FOR M59 GAS-PARTICULATE FILTER UNIT

2-13. GENERAL. These instructions are for use by organizational maintenance personnel. They apply to:

- M59 gas-particulate filter unit
- Housing unit
- Main fan
- Airflow valve
- Power distribution unit
- Compartment control module

2-14. M59 GAS-PARTICULATE FILTER UNIT - MAINTENANCE INSTRUCTIONS.

This task covers

- | | |
|-----------------|-------------|
| a. Installation | c. Repair |
| b. Removal | d. Painting |
-

INITIAL SETUP

Tools

General Mechanics Tool
Kit SC5180-90-CL-N26

| LOCATION | ITEM | ACTION |
|----------|------|--------|
|----------|------|--------|

REMOVAL

M59 Gas-Particulate
Filter Unit/Power
Distribution Unit

Green tubing
(nonmetallic)

Unscrew green tube coupling nut (1) from connector (2)


Unscrew green tube coupling nut (3) from connector (4)

Pull green tube coupling nuts with sleeves (1 and 3) off tube (5). See detail A

Unscrew red tube coupling nut (6) from connector (7)

Unscrew red tube coupling nut (8) from connector (9).

Pull red tube coupling nuts with sleeves (6 and 8) off tube (10).



DETAIL A

REPAIR

Tubing
(nonmetallic)

Fabricate tubing. Refer to appendix E, figure E-2


2-14. M59 GAS-PARTICULATE FILTER UNIT - MAINTENANCE INSTRUCTIONS (CONT).

| LOCATION | ITEM | ACTION |
|----------|------|--------|
|----------|------|--------|

INSTALLATION

M59 Gas-Particulate
Filter Unit/Power
Distribution Unit

Red tubing
(nonmetallic)



DETAIL A

Push red tube coupling nuts (6 and 8) with sleeves on red tube (10). See detail A.

Push one end of tube (10) into connector (7) and one end into connector (9). RED dot on power distribution unit indicates connector (9).

Push red tube coupling nut (6) with sleeve onto connector (7) and hand tighten.

Push red tube coupling nut (8) with sleeve onto connector (9) and hand tighten.


Green tubing
(nonmetallic)

Push green tube coupling nuts (1 and 3) with sleeves on green tube (5). See detail A.

Push one end of green tube (5) into connector (2) and one end into connector (4). GREEN dot on power distribution unit indicates connector (4).

Push green tube coupling nut (1) with sleeve onto connector (2) and hand tighten.

Push green tube coupling nut (3) with sleeve onto connector (4) and hand tighten.



2-14. M59 GAS-PARTICULATE FILTER UNIT - MAINTENANCE INSTRUCTIONS (CONT).

| LOCATION | ITEM | ACTION |
|----------|------|--------|
|----------|------|--------|



REMOVAL

M59 Gas-Particulate
Filter Unit

Identification
plate

Lift edge of plate with a sharp tool.

Pull plate completely off the mounting surface

INSTALLATION

Thoroughly clean mounting surface with dry-cleaning solvent (item 4, app D) Mounting surface must be free of all contamination such as oil, grease, dirt or any foreign matter

Peel back paper from adhesive backing on plate (1).

Mount plate (1) and apply pressure to plate surface.

PAINTING

Filter housing,
compartment control
module and
power distribution
unit

Touch-up painting is authorized.

Thoroughly clean the surfaces to be repainted. Use ra (item 6, app D) and dry-cleaning solvent (item 4, app I) Paint surfaces with one coat of primer (item 5, app D).

Paint primed surfaces with aliphatic polyurethane coat (item 2, app D).

NOTE

Refer to TM 43-0139 for painting instructions for field use.

2-15. HOUSING UNIT MAINTENANCE INSTRUCTIONS.

This task covers.

- a. Removal
 c Repair
 e Installation
- b Disassembly
 d. Reassembly

INITIAL SETUP

Tools

- General Mechanics Tool Kit
- SC 5180-90-CL-N26
- Torque wrench 0-500 inch-pounds

General Safety Instructions

The unit commander or senior officer in charge of maintenance personnel assigned to remove and dispose of the contaminated gas and particulate filters must prescribe the necessary protective clothing (TM 10-277) to be worn during this operation. He must also prescribe the necessary safety measures to be followed including the decontamination operation (TM 3-220) that must be performed before the new filters are installed


| LOCATION | ITEM | ACTION |
|----------|------|--------|
|----------|------|--------|

REMOVAL

Access cover

Instruction plates

Lift edge of plates (1, 2 or 3) with a sharp tool. Pull plates completely off the mounting surface.



INSTALLATION

Thoroughly clean mounting surface with dry-cleaning solvent (item 4, app D). Mounting surface must be free of all contamination such as oil, grease, dirt or any foreign matter

Peel back paper from adhesive backing on plates (1, 2, or 3)

Mount the plates (1, 2, or 3) and apply pressure to the plate surface

| LOCATION | ITEM | ACTION |
|----------|------|--------|
|----------|------|--------|

REMOVAL

NOTE

The unit commander or senior officer in charge of maintenance personnel assigned to remove and dispose of the contaminated gas and particulate filters must prescribe the necessary protective clothing (TM 10-277) to be worn during this operation. He must also prescribe the necessary safety measures to be followed including the decontamination operation (TM 3-220) that must be performed before the new filters are installed.

Housing
unit

Particulate
filters



Set POWER switch (1) on compartment control module to OFF.

Loosen screw (2).

Pull catch (3) outward and swing retaining bar (4) away from inner cover (5).

Using handles, pull inner cover (5) from access cover (6).

Pull two particulate filters (7) from filter housing (8).



CCM

INSTALLATION

Particulate
filters

Place the particulate filters (7) in filter housing (8), either end first.


Grasp inner cover by the handles and place it in the access cover (6).

Swing retaining bar (4) up across inner cover and engage end of bar with catch (3).

WARNING

Filter seals must be properly seated to prevent bypass of contaminated air.

Tighten screw (2) until sleeve (9) is flush with top surface (A) of retaining bar (4).



2-15. HOUSING UNIT — MAINTENANCE INSTRUCTIONS (CONT).

| LOCATION | ITEM | ACTION |
|----------|------|--------|
|----------|------|--------|

REMOVAL


NOTE

The unit commander or senior officer in charge of maintenance personnel assigned to remove and dispose of the contaminated gas and particulate filters must prescribe the necessary protective clothing (TM 10-277) to be worn during this operation. He must also prescribe the necessary safety measures to be followed including the decontamination operation (TM 3-220) that must be performed before the new filters are installed.

Housing
unit

Gas and
particulate
filters

Set POWER switch (1) on the compartment control module to OFF.




Loosen screw (2)

Pull catch (3) outward and swing retaining bar (4) away from inner cover (5).

Using handles, pull inner cover (5) from access cover (6).

Pull the two particulate filters (7) from filter housing (8)



| LOCATION | ITEM | ACTION |
|----------|------|--------|
|----------|------|--------|

REMOVAL (CONT)


Housing
Unit

Gas and
particulate
filters

Remove screws (9), aluminum washer (10), and washer (11).

Pull access cover (6) from housing (8).

Pull the two gas filters (12) from filter housing (8).




REPAIR

Filter Housing/
Inner Cover

Seals

Replace access cover seal (13) on filter housing or seal (14) on inner cover (5) if unserviceable.

- Remove seal from groove.
- Clean groove using solvent (item 4, app D).
- Install seal in groove and butt end using adhesive (item 1, app D).



2-15. HOUSING UNIT — MAINTENANCE INSTRUCTIONS (CONT).

LOCATION


ITEM

ACTION

INSTALLATION

Housing Unit

Gas filter



Place the two gas filters (12) in filter housing (8), either end first.

Position access cover (6) on filter housing. Align guide pin with guide hole (15). Push access cover (6) into place.

NOTE

To prevent binding of outer access cover against filter housing rim, screws must be tightened alternately in a criss-cross pattern.


Install washers (11), aluminum washers (10), and screws (9) finger tight.

WARNING

Filter seals must be properly seated to prevent bypass of contaminated air.

CAUTION

Be sure to observe torque values for the torque wrench being used.



Particulate filter

Preliminary torque In a crisscross pattern, torque screws to 8-10 foot-pounds (100 - 125 inch-pounds).

Final torque In a crisscross pattern, torque screws to 15-16 foot-pounds (180 - 200 inch-pounds).

Place the two particulate filters (7) in gas filters (12) either end first.



Grasp inner cover (5) by the handles and place it in the access cover (6).

Swing retaining bar (4) up across inner cover and engage end of bar with catch (3).

WARNING

Filter seals must be properly seated to prevent bypass of contaminated air.

Tighten screw (2) until sleeve (16) is flush with top surface (A) of retaining bar (4).

| LOCATION | ITEM | ACTION |
|---|---|--|
| REMOVAL | | |
| Housing Unit | Dust and moisture seal protective cap | Loosen moisture seal protective cap adjusting screw (1) and remove protective cap (2) from inlet tee (3) |
| | | Remove nut (4) and washer (5) from screw (6) |
| | | Remove screw (6) from inlet tee (3), loop of support cable (7) with dust and moisture seal protective cap (2), and washer (8). |
|  | | |
| DISASSEMBLY | | |
| | | Remove nut (9) and washer (10) from screw (11). |
| | | Remove screw (11) from rubber cap (2), loop of support cable (7), and washer (12). |
| | | Remove hose clamp (13) from rubber cap (2) |
|  | | |
| REPAIR | | |
| | Support cable | Fabricate support cable. Refer to appendix E, figure E |


2-15. HOUSING UNIT — MAINTENANCE INSTRUCTIONS (CONT).

LOCATION

ITEM

ACTION

REASSEMBLY



Insert screw (11) in washer (12), loop of support cable (7) and hole in rubber cap (2)


Install washer (10) and nut (9). Tighten securely

Install hose clamp (13) in groove in rubber cap (2).

INSTALLATION

Housing
Unit

Dust and moisture
seal protective
cap



Insert screw (6) in washer (8), loop of support cable (7), and hole in inlet tee (3)

Install washer (5) and nut (4). Tighten securely.

Place moisture seal protective cap (2) on inlet tee (3). Tighten adjusting screw (1).

2-16. MAIN FAN - MAINTENANCE INSTRUCTIONS.

This task covers

- a. Removal
- b. Installation

INITIAL SETUP

Tools
General Mechanics Tool Kit
SC 5180-90-CL-N26

| LOCATION | ITEM | ACTION |
|----------|------|--------|
|----------|------|--------|

REMOVAL



Housing
Unit

Main fan/
inlet tee

Set POWER switch (1) on compartment control
module to OFF.

Turn off power source.

Disconnect electrical cable plug P4 (2) from power distri-
bution panel connector J4 (3).



2-16. MAIN FAN-MAINTENANCE INSTRUCTIONS (CONT).

| LOCATION | ITEM | ACTION |
|----------|------|--------|
|----------|------|--------|

REMOVAL (CONT)


Housing
Unit

Main fan/
inlet tee

Remove screws (4) and washers (5)

Pull inlet tee (6) with main fan (7) attached from filter housing (8).

Remove main fan cable grommet (9) from filter housing (8). Remove grommet (9) from electrical cable (10)




Inlet Tee

Main fan

Remove screws (11) and washers (12)

Separate main fan (7) from inlet tee (6).



INSTALLATION

Inlet Tee

Main fan

Position main fan (7) up to Inlet tee (6). Aline guide pins (13) on inlet tee with guide pin holes in main fan. Push main fan against Inlet tee.

Install washers (12) and screws (11). Tighten securely.

| LOCATION | ITEM | ACTION |
|----------|------|--------|
|----------|------|--------|

INSTALLATION (CONT)

housing

Main fan/

Install grommet (9) on cable (10) about 10 inches from motor

Inlet


inlet tee

Position inlet tee (6) up to filter housing (8)


Install grommet (9) in slot in face of filter housing (8) with slit away from housing.

Align guide pin hole (14) with guide pin (15). Push inlet tee against filter housing.

Install washers (5) and screws (4). Tighten securely



Connect electrical cable plug P4 (2) to power distribution panel connector J4 (3).



2-17. AIRFLOW VALVE - MAINTENANCE INSTRUCTIONS.

This task covers

- | | |
|----------------|-----------------|
| a. Removal | d. Reassembly |
| b. Disassembly | e. Installation |
| c. Repair | |


INITIAL SETUP

Tools


General Mechanics Tool Kit
SC 5180-90-CL-N26

| LOCATION | ITEM | ACTION |
|----------|------|--------|
|----------|------|--------|

REMOVAL



Set POWER switch (1) on compartment control module to OFF. Turn off power source



Loosen hose clamp adjusting screw (2) and remove adapter mounting hose (3).

Disconnect electrical plug P15 (4) from airflow valve connector J15 (5).

Remove nuts (6), screws (7), and washers (8).

Separate airflow valve (9) from filter unit (10)

REPAIR

Gasket

Replace airflow valve gasket (11) if unserviceable.

Remove gasket from flange on airflow valve

Clean flange using dry-cleaning solvent (item 4, app D).

Peel back paper from adhesive back


Install gasket.

| LOCATION | ITEM | ACTION |
|------------------------|---------------------------------------|--|
| <div>DISASSEMBLY</div> | | |
| Airflow Valve | Dust and moisture seal protective cap | Remove nut (12) from screw (13). Remove screw (13), support cable loop (14), washer (15), support cable loop (16), and washer (17) |
| | | Remove nut (18) and washer (19) from screw (20) |
| | | Remove screw (20) from rubber cap (21), support cable loop (22), and washer (23) |
| | | Loosen adjusting screw (25), and remove hose clamp (24) from rubber cap (21). |
| <div>REPAIR</div> | | |
| | Support cable | Fabricate support cable Refer to appendix E, figure E-1 |
| <div>REASSEMBLY</div> | | |
| Airflow Valve | Dust and moisture seal protective cap | Install screw (20) in washer (23), loop of support cable (22), hole in rubber cap (21), washer (19), and nut (18). Tighten nut securely. |
| | | Install hose clamp (24) in groove in rubber cap (21) Tighten adjusting screw (25) slightly. |
| | | Install screw (13) in washer (17), loop of support cable (16), washer (15), support cable (14), hole in airflow valve, and nut (12). Tighten nut securely. |

2-17. AIRFLOW VALVE - MAINTENANCE INSTRUCTIONS (CONT).

| LOCATION | ITEM | ACTION |
|----------|------|--------|
|----------|------|--------|

INSTALLATION



Place airflow valve against filter housing (10) Align screw holes.

Install washers (8), screws (7), and nuts (6) Tighten securely.


Connect electrical plug P15 (4) to airflow valve connector J15 (5).

Install adapter mounting hose (3) on airflow valve. Tighten hose clamp adjusting screw (2)

REMOVAL

Airflow Valve Identification plate and instruction plates Lift edge of plate (1, 2, or 3) with a sharp tool Pull plate completely off the mounting surface

INSTALLATION



Thoroughly clean mounting surface with dry-cleaning solvent (item 4, app D). Mounting surface must be free of all contamination such as oil, grease, dirt or any foreign matter.

Peel back paper from adhesive backing on plate.

Mount plate and apply pressure to plate surface

2-18. POWER DISTRIBUTION UNIT - MAINTENANCE INSTRUCTIONS.

This task covers

- a. Removal b. Installation

INITIAL SETUP

Tools

General Mechanics Tool Kit
SC 5180-90-CL-N26

General Safety Instructions

If filter unit is operating, 208V is present
at the indicator lamp socket.

| LOCATION | ITEM | ACTION |
|----------|------|--------|
|----------|------|--------|

REMOVAL


PATRIOT
Housing Unit

Power distribution unit

Turn off power source.

Disconnect cables from PDU.

Remove bolts (1), washers (2), and nuts (3).



INSTALLATION

Install power distribution unit using bolts (1),
washers (2), and nuts (3).

Connect cables to PDU.

Turn power source on.

2-18. POWER DISTRIBUTION UNIT - MAINTENANCE INSTRUCTIONS (CONT).


| LOCATION | ITEM | ACTION |
|----------|------|--------|
|----------|------|--------|

REMOVAL

Power Distribution Panel

Glow lamp

Loosen screws (1)



Open access cover (2) on power distribution panel (3).

Unscrew lens (4).

WARNING

If filter unit is operating, 208 V is present at the indicator lamp socket.

Remove glow lamp (5) from indicator lamp socket (6).

INSTALLATION

Insert glow lamp (5) in lens (4).

Screw lens (4) into indicator lamp socket (6)

Close access cover (2) against panel (3) and secure with screws (1)

REMOVAL


Power Distribution Panel

Identification plate

Lift edge of plate (1) with a sharp tool.

Pull plate completely off the mounting surface.

INSTALLATION



Thoroughly clean mounting surface with dry-cleaning solvent (item 4, app D). Mounting surface must be free of all contamination such as oil, grease, dirt or any foreign matter.

Peel back paper from adhesive backing on plate (1).

Mount plate (1) and apply pressure to plate surface.

2-19. COMPARTMENT CONTROL MODULE - MAINTENANCE INSTRUCTIONS.

This task covers

- a. Removal
- b. Repair

c. Installation

INITIAL SETUP

Tools


General Mechanics Tool Kit
SC 5180-90-CL-N26

| LOCATION | ITEM | ACTION |
|----------|------|--------|
|----------|------|--------|

REMOVAL

PATRIOT

Compartment control module



Set POWER switch (1) on compartment control module to OFF. Turn off Power at source.

Disconnect electrical cable plug P1 (2) from compartment control module.

Pull off pressure hose (3).

Remove screws (4), washers (5), and compartment control module from mounting brackets

REPAIR

Hose

Fabricate replacement hose (fig. E-3B, app E).

INSTALLATION

Compartment control module

Place compartment control module against mounting brackets and align with screw holes.

Install washers (4) and screws (5). Tighten securely.

Install pressure hose (3).

Connect electrical cable plug P1 (2) to connector J1 on compartment control module.

2-19. COMPARTMENT CONTROL MODULE - MAINTENANCE INSTRUCTIONS (CONT).

| LOCATION | ITEM | ACTION |
|----------|------|--------|
|----------|------|--------|

REMOVAL

Compartment Control
Module


MASK lamp

Using two screwdrivers, gently pry lens (1) from control panel (2)

NOTE

Observe the location of lamps in the lens
Lamps must be re-installed in the same
sockets

Pull lamps (3) from lens (1)



LOW PRESSURE lamp

Same as MASK lamp.

OCCUPIED lamp

Same as MASK lamp

CHANGE FILTER lamp

Unscrew lens (4) Remove lamp (5)

INSTALLATION

MASK lamp

Insert lamps (3) into lens (1). Use the same lamp socket
that lamps were removed from.

Insert lens (1) into control panel (2), as shown in detail
Press lens into panel til it snaps into place.

LOW PRESSURE lamp

Same as MASK lamp.


OCCUPIED lamp

Same as MASK lamp.

CHANGE FILTER lamp

Insert lamp (5) into lens (4).

Screw lens (4) into control panel (2)



DETAIL

A


Section VIII MAINTENANCE PROCEDURES FOR M265 INSTALLATION KIT

- 2-20. **GENERAL.** These instructions are for use by organizational maintenance personnel. They apply to:
- Cables
 - Air duct hoses
 - Transition

2-21. CABLE - MAINTENANCE INSTRUCTIONS.

NOTE:

Use The Cable Routing Diagram Below To Locate Each Of The Five Cables.



SPECIAL PURPOSE ELECTRICAL CABLE ROUTING DIAGRAM

2-22. CABLE C5-19-6162-20 - MAINTENANCE INSTRUCTIONS.

This task covers

- | | |
|-----------|----------------|
| a Removal | c Replace |
| b Test | d Installation |

INITIAL SETUP

Test Equipment
Multimeter

| LOCATION | ITEM | ACTION |
|----------|------|--------|
|----------|------|--------|

REMOVAL


M14 Protective
Entrance and
Power Distribution
Unit

Cable C5-19-6162-20

Set compartment control module POWER switch (1)
to OFF.
Shut down power source

Disconnect electrical cable plug P20 (2) from protective
entrance connector J20 (3)

Disconnect electrical cable plug P5 (4) from power distri-
bution unit connector J5 (5)



LOCATION

ITEM

ACTION


TEST

Cable C5-19-6162-20

Check continuity of each wire between P5 and P20.

NOTE


Use multimeter and cable C5-19-6162-20 wiring diagram.



C5-19-6162-20
CABLE ASSEMBLY WIRING DIAGRAM

Cable C5-19-6162-20

Replace cable if it fails continuity check



2-22. CABLE C5-19-6162-20 - MAINTENANCE INSTRUCTIONS (CONT).

| LOCATION | ITEM | ACTION |
|----------|------|--------|
|----------|------|--------|

INSTALLATION


M14 Protective
Entrance and
Power Distribution
Unit

Cable C5-19-6162-20

Set POWER switch (1) on compartment control module to OFF. Turn off power source.

Connect electrical cable plug P5 (4) to power distribution unit connector J5 (5).

Connect electrical cable plug P20 (2) to protective entrance connector J20 (3).



2-23. CABLE C5-19-6170-10 - MAINTENANCE INSTRUCTIONS.

This task covers

- a Removal
- b Test

- c Replace
- d Installation

INITIAL SETUP

Test Equipment
Multimeter

| LOCATION | ITEM | ACTION |
|----------|------|--------|
|----------|------|--------|

REMOVAL

Power Distribution
Unit and
Airflow Valve


Cable C5-19-6170-10

Set compartment control module POWER switch (1)
to OFF

Turn off power source.

Disconnect electrical cable assembly plug P2 (2) from
PDU connector J2 (3).

Disconnect electrical cable assembly plug P15 (4) from
airflow valve connector J15 (5)



2-23. CABLE C5-19-6170-10 - MAINTENANCE INSTRUCTIONS (CONT).

| LOCATION | ITEM | ACTION |
|----------|------|--------|
|----------|------|--------|

TEST


Power Distribution Unit
and Airflow Valve

Cable C5-19-6170-10

Check continuity of each wire between P2 and P15.

NOTE

Use multimeter and cable C5-19-6170-10
wiring diagram




REPLACE

Power Distribution Unit
and Airflow Valve

Cable C5-19-6170-10

Replace cable if it fails continuity check



| LOCATION | ITEM | ACTION |
|----------|------|--------|
|----------|------|--------|

INSTALLATION


Power Distribution
Unit and Airflow
Valve

Cable C5-19-6170-10

Set POWER switch (1) on compartment control module to OFF. Turn off power source.

Connect electrical cable assembly plug P15 (4) to airflow valve connector J15 (5).

Connect electrical cable assembly plug P2 (2) to power distribution unit connector J2 (3).



2-24. CABLE W91 - MAINTENANCE INSTRUCTIONS.

This task covers

- | | |
|------------|-----------------|
| a. Removal | c. Replace |
| b. Test | d. Installation |

INITIAL SETUP

Test Equipment
Multimeter

| LOCATION | ITEM | ACTION |
|----------|------|--------|
|----------|------|--------|

REMOVAL


Compartment Control
Module and Feed-Thru
Connector

Cable W91

Set compartment control module POWER switch (1) to OFF. Turn off power source.

Disconnect electrical cable assembly plug P1 (2) from compartment control module connector J1 (3).

Disconnect electrical cable assembly plug P3 (4) from feed-thru connector J5 (5).



TEST

Check continuity of each wire between P1 and P3.

LOCATION

ITEM


ACTION

REPLACE

Compartment
Control Module and
Feed-Thru
Connector

Cable W91

Replace cable if it fails continuity check



INSTALLATION


Compartment
Control Module and
Feed-Thru Connector

Cable W91

Set compartment control module POWER switch
(1) to OFF. Turn power off source

Connect electrical cable assembly plug P3 (4) to feed-
thru connector J5 (5)

Connect electrical cable assembly plug P1 (2) to
compartment control module connector J1 (3)



2-25. CABLE W90 - MAINTENANCE INSTRUCTIONS.

This task covers

- a Removal
- b Test
- c. Replace
- d. Installation

INITIAL SETUP

Test Equipment
Multimeter



| LOCATION | ITEM | ACTION |
|----------|------|--------|
|----------|------|--------|

REMOVAL

Power Distribution
Unit and
Feed-Thru
Connector

Cable W90

- Set compartment control module POWER switch (1) to OFF. Turn off power source
- Disconnect electrical cable assembly plug P1 (2) from feed-thru connector J5 (3)
- Disconnect electrical cable assembly plug P3 (4) from power distribution unit connector J3 (5)



| LOCATION | ITEM | ACTION |
|----------|------|--------|
|----------|------|--------|

TEST


Check continuity of each wire between P1 and P3

REPLACE

Power Distribution
Unit and
Feed-Thru
Connector

Cable W90

Replace cable if it fails continuity check



INSTALLATION

Power Distribution
Unit and
Feed-Thru
Connector

Cable W90

Set compartment control module POWER switch (1) to OFF. Turn off power source.

Connect electrical cable assembly plug P3 (4) to power distribution unit connector J3 (5).

Connect electrical cable assembly plug P1 (2) to feed-thru connector J5 (3).

2-26. C5-19-6712 - MAINTENANCE INSTRUCTIONS.

This task covers:

- a. Removal
- b. Test
- c. Replace
- d. Installation

INITIAL SETUP

Test Equipment
Multimeter

| LOCATION | ITEM | ACTION |
|----------|------|--------|
|----------|------|--------|

REMOVAL

WARNING

Before removing power cable, be sure that POWER switch on compartment control is set to OFF position and that the collective protection equipment power source is shut down to avoid injury or loss of life.


Power Distribution
Unit and
Power Source
Connector

Cable C5-19-6712

Set compartment control module POWER switch (1) to OFF. Turn off power source.

Disconnect cable assembly plug P7 (2) from power distribution unit connector J7 (3).

Disconnect electrical cable assembly plug P16 (4) from power source connector J26 (5).



| LOCATION | ITEM | ACTION |
|----------|------|--------|
|----------|------|--------|


TEST

Power Distribution
Unit and Power
Source Connector

Check continuity of each wire between P7 and P16

NOTE

Use multimeter and cable C5-19-6712 wiring diagram.




C5-19-6712
CABLE WIRING DIAGRAM

REPLACE

Power Distribution
Unit and Power
Connector

Cable C5-19-6712

Replace cable if it fails continuity check



INSTALLATION

WARNING

Before removing power cable, be sure that POWER switch on compartment control is set to OFF position and that the collective protection equipment power source is shut down to avoid injury or loss of life.

Power Distribution
Unit and
Power Source
Connector

Cable C5-19-6712

Set compartment control module POWER switch (1) to OFF. Turn off power source.

Connect electrical cable assembly plug P16 (4) to power source connector J26 (5) at feed-thru.

Connect electrical cable assembly plug P7 (2) to power distribution unit connector J7 (3).

2-28. FOUR DUCT ADAPTER - MAINTENANCE INSTRUCTIONS.

This task covers

a Removal

c Installation

b Replace/Repair

INITIAL SETUP**Tools**

General Mechanics Tool Kit
SC 5180-90-CL-N26

| LOCATION | ITEM | ACTION |
|----------|------|--------|
|----------|------|--------|


REMOVAL

Airflow Valve

Four duct
adapter

Loosen hose clamp adjusting screws (5). Pull air duct hoses (1), (2) and (3) from adapter (4)

Loosen adapter mounting hose clamp adjusting screws (7). Pull adapter (4) from airflow valve (6). Pull adapter mounting hose (8) from adapter.



| LOCATION | ITEM | ACTION |
|----------|------|--------|
|----------|------|--------|


REPLACE/REPAIR

Airflow Valve

Mounting
hose

Replace if defective

Loosen clamp (7) to remove mounting hose (8). Install replacement hose and clamp unit.



INSTALLATION


Airflow Valve

Four duct
adapter

Place adapter mounting hose (8) over top port (9) on adapter (4). Tighten adapter clamp adjusting screw (7) securely. Place adapter mounting hose in airflow valve port marked TO SHELTER (6).

Place air duct hoses (1) (2) and (3) over adapter ducts (9) (10) and (11). Place PE air duct hose (1) over duct (9). Place air conditioner air duct hoses (2 and 3) over ducts (10) and (11).

Tighten hose clamp adjusting screws (5) securely.



APPENDIX A REFERENCES

The following publications are related to information contained in this manual.

A-1. TECHNICAL MANUALS.

| | |
|---------------------------|---|
| TM 3-220 | Chemical, Biological and Radiological (CBR) Decontamination |
| *TM 9-1430-600-12-1 | Operation and Organizational Maintenance Instructions, Engagement Control Station, Guided Missile, Truck Mounted, AN/MSQ-104 (XO-1) |
| *TM 9-1430-602-12-1 | Operation and Organizational Maintenance Instructions, Information and Coordination Central, Guided Missile, Truck Mounted, AN/MSQ-116 (XO-1) |
| *TM 9-1430-604-12-1 | Operation and Organizational Maintenance Instructions, Communications Relay Group, Guided Missile, Truck Mounted, AN/MRC-137 (XO-1) |
| TM 10-277 | Chemical, Toxicological and Missile Fuel Handlers Protective Clothing |
| TM 38-750 | The Army Maintenance Management System (TAMMS) |
| TM 43-0002-31 | Destruction of Chemical Weapons and Defense Equipment to Prevent Enemy Use |
| TM 43-0139 | Painting Instructions for Field Use |
| TM 740-90-1 | Administrative Storage of Equipment |

A-2. COMMON TABLE OF ALLOWANCES.

| | |
|------------------|---|
| CTA 50-970 | Expendable Items (Except: Medical Class V R Parts and Heraldic Items) |
|------------------|---|

A-3. SUPPLY BULLETIN.

| | |
|--------------------|---|
| SB 708-41/42 | Federal Supply Code for Manufacturers; Unit and Canada — Name to Code and Code to I |
|--------------------|---|

A-4. SUPPLY CATALOG.

| | |
|-------------------------|---|
| SC 5180-90-CL-N26 | Tool Kit, General Mechanics; Automotive |
|-------------------------|---|

APPENDIX B

MAINTENANCE ALLOCATION CHART

Section I INTRODUCTION

B-1. GENERAL.

- a. This section provides a general explanation of all maintenance and repair functions authorized at various maintenance categories.
- b. The maintenance allocation chart (MAC) in Section II designates overall responsibility for the performance of maintenance functions on the identified end item or component. The implementation of the maintenance functions upon the end item or component will be consistent with the assigned maintenance functions.
- c. Section III lists the special tools and test equipment required for each maintenance function as referenced from Section II.
- d. Section IV contains supplemental instructions and explanatory notes for a particular maintenance function.
- d. *Adjust*. To maintain, within prescribed limits, by bringing into proper or exact position, or by setting the operating characteristics to specified parameters.
- e. *Align*. To adjust specified variable elements of an item to bring about optimum or desired performance.
- f. *Calibrate*. To determine and cause corrections to be made or to be adjusted on instruments or test, measuring, and diagnostic equipments used in precision measurement. Consists of comparisons of two instruments, one of which is a certified standard of known accuracy, to detect and adjust any discrepancy in the accuracy of the instrument being compared.
- g. *Install*. The act of emplacing, seating, or fixing into position an item, part, or module (component or assembly) in a manner to allow the proper functioning of an equipment or system.

B-2. MAINTENANCE FUNCTIONS. Maintenance functions will be limited to and defined as follows:

- a. *Inspect*. To determine the serviceability of an item by comparing its physical, mechanical, and/or electrical characteristics with established standards through examination.
- b. *Test*. To verify serviceability by measuring the mechanical or electrical characteristics of an item and comparing those characteristics with prescribed standards.
- c. *Service*. Operations required periodically to keep an item in proper operating condition, i.e., to clean (includes decontaminate, when required), to preserve, to drain, to paint, or to replenish fuel, lubricants, chemical fluids, or gases.
- h. *Replace*. The act of substituting a serviceable like type part, subassembly, or module (component or assembly) for an unserviceable counterpart.
- i. *Repair*. The application of maintenance services¹ or other maintenance actions² to restore serviceability to an item by correcting specific damage, fault, malfunction, or failure in a part, subassembly, module (component or assembly), end item, or system.
- j. *Overhaul*. That maintenance effort (service/action) necessary to restore an item to a completely serviceable/operational condition as prescribed by maintenance standards in appropriate technical publications (i.e., DMWR). Overhaul is normally the highest degree of maintenance performed by the Army. Overhaul does not normally return an item to like new condition.

¹ Services - inspect, test, service, adjust, align, calibrate, or replace.

² Actions - welding, grinding, riveting, straightening, facing, remachining, or resurfacing.

- k. *Rebuild.* Consists of those services/actions necessary for the restoration of un-serviceable equipment to a like new condition in accordance with original manufacturing standards. Rebuild is the highest degree of materiel maintenance applied to Army equipment. The rebuild operation includes the act of returning to zero those age measurements (hours/miles, etc) considered in classifying Army equipments/components.

B-3. EXPLANATION OF COLUMNS IN THE MAC, SECTION II.

- a. *Column 1, Group Number.* Column 1 lists functional group code numbers, the purpose of which is to identify components, assemblies, subassemblies, and modules with the next higher assembly.
- b. *Column 2, Component/Assembly.* Column 2 contains the names of components, assemblies, subassemblies, and modules for which maintenance is authorized.
- c. *Column 3, Maintenance Function.* Column 3 lists the functions to be performed on the item listed in Column 2. (For detailed explanation of these functions, see paragraph B-2.)
- d. *Column 4, Maintenance Category.* Column 4 specifies, by the listing of a work time figure in the appropriate subcolumn(s), the category of maintenance authorized to perform the function listed in Column 3. This figure represents the active time required to perform that maintenance function at the indicated category of maintenance. If the number or complexity of the tasks within the listed maintenance function vary at different maintenance categories, appropriate work time figures will be shown for each category. The work time figure represents the average time required to restore an item (assembly, subassembly, component, module, end item, or system) to a serviceable condition under typical field operating conditions. This time includes preparation time, troubleshooting time, and quality assurance/quality control time in addition to the time required to perform the specific

tasks identified for the maintenance functions authorized in the maintenance allocation chart. The symbol designations for the various maintenance categories are as follows:

- C Operator or crew.
- O Organizational maintenance.
- F Direct support maintenance.
- H General support maintenance.
- D Depot maintenance.
- e. *Column 5, Tools and Equipment.* Column 5 specifies, by code, those common tool sets (not individual tools) and special tools, TMDE, and support equipment required to perform the designated function
- f. *Column 6, Remarks.* This column shall, when applicable, contain a letter code, in alphabetic order, which shall be keyed to the remarks contained in Section IV.

B-4. EXPLANATION OF COLUMNS IN TOOL AND TEST EQUIPMENT REQUIREMENTS, SECTION III.

- a. *Column 1, Reference Code.* The tool and test equipment reference code correlates with a code used in the MAC, Section II, Column 5
- b. *Column 2, Maintenance Category.* The lowest category of maintenance authorized to use the tool or test equipment.
- c. *Column 3, Nomenclature.* Name or identification of the tool or test equipment.
- d. *Column 4, National Stock Number.* The National stock number of the tool or test equipment.
- e. *Column 5, Tool Number.* The manufacturer's part number.

B-5. EXPLANATION OF COLUMNS IN REMARKS, SECTION IV.

- a. *Column 1, Reference Code.* The code recorded in column 6, Section II.
- b. *Column 2, Remarks.* This column lists information pertinent to the maintenance function being performed as indicated in the MAC, Section II.

SECTION II MAINTENANCE ALLOCATION CHART

| (1) GROUP NUMBER | (2) COMPONENT ASSEMBLY | (3) MAINTENANCE FUNCTION | (4) MAINTENANCE CATEGORY | | | | | (5) TOOLS AND EQUIP. | (6) REMARKS |
|------------------------|--|--------------------------------------|-----------------------------|--------------------------|-----|---|-----|--|----------------|
| | | | C | O | F | H | D | | |
| 0100 | M14 PROTECTIVE ENTRANCE | Inspect Test Replace Repair | | 0.1 0.2 0.5 0.2 | | | | 4 1 | A |
| 0110 | PROTECTIVE ENTRANCE CONTROL MODULE | Test Replace Repair | | | 0.5 | | | 4, 5, 6, 8, 9, 10, 11, 12, 13, 14 1 1, 2 | |
| 0200 | M59 GAS- PARTICULATE FILTER UNIT | Inspect Test Repair | | 0.5 0.2 1.0 | | | | 4 1, 3 | B |
| 0210 | HOUSING UNIT | Repair | | 0.5 | | | | 1 | |
| 0211 | MAIN FAN | Replace Repair | | 0.5 | | | 1.0 | 1 | |
| 0212 | AIRFLOW VALVE | Test Replace Repair | | | 0.2 | | | 4, 5, 12 1 1, 2 | |
| 0220 | POWER DISTRIBUTION UNIT | Replace Repair | | 0.2 | | | | 1 2 | |
| 0221 | POWER DISTRIBUTION PANEL | Test Repair | | | 0.5 | | | 4, 5, 6, 7, 9, 10, 11, 12, 13 1, 2 | |
| 0230 | COMPARTMENT CONTROL MODULE | Test Replace Repair | | | 0.5 | | | 4, 5, 6, 8, 9, 10, 11, 12, 13 1 1, 2 | |
| 0300 | M265 INSTALLATION KIT | Test Inspect Repair | | 0.2 0.1 0.3 | | | | 4 | |

Section III TOOL AND TEST EQUIPMENT REQUIREMENTS

| TOOL OR TEST EQUIPMENT REF CODE | MAINTENANCE CATEGORY | NOMENCLATURE | NATIONAL/NATO STOCK NUMBER | TOOL NUMBER |
|---------------------------------------|-------------------------|--|-------------------------------------|-------------------|
| 1 | O | TOOL KIT, GENERAL MECHANICS | 5180-00-177-7003 | SC 5180-90-CL-N26 |
| 2 | F | TOOL KIT, ELECTRONIC EQUIPMENT | 5180-00-610-8177 | SC 5180-91-CL-R07 |
| 3 | O | WRENCH, TORQUE | 5120-00-247-2536 | Model 260-7P |
| 4 | O | MULTIMETER | 6625-01-092-1197 | |
| 5 | F | POWER SUPPLY, DIRECT CURRENT | 6130-00-408-4962 (or equivalent) | |
| 6 | F | GAGE, DIFFERENTIAL, DIAL INDICATING, 0-6 inches (H ² O) | 6685-00-087-6331 | |
| 7 | F | RESISTOR, 680 OHM, ±5%, 2 WATT | 5905-00-256-0390 | CX-1331A/U |
| 8 | F | RESISTOR, 100 OHM ±, 10% WATT | 5905-00-752-6460 | |
| 9 | F | SYRINGE, HYPODERMIC | 6515-00-754-0412 | |
| 10 | F | TEE, HOSE | 4730-00-082-5402 | |
| 11 | F | TUBING, NONMETALLIC | 4720-00-059-5819 | |
| 12 | F | LEAD SET, TEST | 6625-00-395-9313 | |
| 13 | F | LEAD SET, TEST | 6625-00-444-4041 | |
| 14 | F | ADAPTER, PIPE TO HOSE | 4730-00-782-5582 | |

Section IV. REMARKS

| REFERENCE CODE | REMARKS |
|----------------|---|
| A | Removed and installed by crew |
| B | Depot to accumulate for future repair/disposition |

APPENDIX C REPAIR PARTS AND SPECIAL TOOLS LIST

Section I INTRODUCTION

C-1. SCOPE. This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of organizational maintenance of the collective protection equipment. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

C-2. GENERAL. This Repair Parts and Special Tools List is divided into the following sections:

- a. *Section II. Repair Parts List.* A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence. Bulk materials are listed in NSN sequence.
- b. *Section III. Special Tools List.* Not applicable.
- c. *Section IV. National Stock Number and Part Number Index.* A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list in alphameric sequence of all parts numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

C-3. EXPLANATION OF COLUMNS.

- a. *Illustration.* This column is divided as follows:
 - (1) *Figure Number.* Indicates the figure number of the illustration on which the item is shown.

- (2) *Item Number.* The number used to identify item called out in the illustration.

- b. *Source, Maintenance, and Recoverability (SMR) Codes.*

- (1) *Source Code.* Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows:

| Code | Definition |
|------|---|
| PA | Item procured and stocked for anticipated or known usage. |
| PB | Item procured and stocked for insurance purpose because essentiality dictates that a minimum quantity be available in the supply system. |
| PC | Item procured and stocked and which otherwise would be coded PA except that it is deteriorative in nature. |
| PD | Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment. |
| PE | Support equipment procured and stocked for initial issue or outfitting to specified maintenance repair activities. |
| PF | Support equipment which will not be stocked but which will be centrally procured on demand. |
| PG | Item procured and stocked to provide for sustained support for the life of the equipment. It is applied to an item peculiar to the equipment which, because of probable discontinuance or shutdown of production facilities, would prove uneconomical to reproduce at a later time. |

| <i>Code</i> | <i>Definition</i> |
|-------------|---|
| KD | An item of a depot overhaul/repair kit and not purchased separately. Depot kit defined as a kit that provides items required at the time of overhaul or repair. |
| KF | An item of a maintenance kit and not purchased separately. Maintenance kit defined as a kit that provides an item that can be replaced at organizational or intermediate levels of maintenance. |
| KB | Item included in both a depot overhaul/repair kit and a maintenance kit. |
| MO | Item to be manufactured or fabricated at organizational level. |
| MF | Item to be manufactured or fabricated at the direct support maintenance level. |
| MH | Item to be manufactured or fabricated at the general support maintenance level. |
| MD | Item to be manufactured or fabricated at the depot maintenance level. |
| AO | Item to be assembled at organizational level. |
| AF | Item to be assembled at direct support maintenance level. |
| AH | Item to be assembled at general support maintenance level. |
| AD | Item to be assembled at depot maintenance level. |
| XA | Item is not procured or stocked because the requirements for the item will result in the replacement of the next higher assembly. |
| XB | Item is not procured or stocked. If not available through salvage, requisition. |
| XC | Installation drawing, diagram, instruction sheet, field service drawing, that is identified by manufacturer's part number. |
| XD | A support item that is not stocked. When required, item will be procured through normal supply channels. |

NOTE

Cannibalization or salvage may be used as a source of supply for any items coded above except those coded XA.

(2) *Maintenance Code* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

- (a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

| <i>Code</i> | <i>Application/Explanation</i> |
|-------------|---|
| C | Crew or operator maintenance performed within organizational maintenance. |
| O | Support item is removed, replaced, used at the organizational level. |
| F | Support item is removed, replaced, used at the direct support level. |
| H | Support item is removed, replaced, used at the general support level. |
| D | Support items that are removed, replaced, used at depot, mobile depot, or specialized repair activity only. |

- (b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes.

| <i>Code</i> | <i>Application/Explanation</i> |
|-------------|--|
| O | The lowest maintenance level capable of complete repair of the support item is the organizational level. |
| F | The lowest maintenance level capable of complete repair of the support item is the direct support level. |

| <i>Code</i> | <i>Application/Explanation</i> |
|-------------|---|
| H | The lowest maintenance level capable of complete repair of the support item is the general support level. |
| D | The lowest maintenance level capable of complete repair of the support item is the depot level. |
| L | Repair restricted to specialized repair activity. |
| Z | Nonreparable. No repair is authorized. |
| B | No repair is authorized. The item may be reconditioned by adjusting, lubricating, etc., at the user level. No parts or special tools are procured for the maintenance of this item. |
| | (3) <i>Recoverability Code.</i> Recoverability codes are assigned to support items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows: |

| <i>Recoverability Codes</i> | <i>Definition</i> |
|-----------------------------|---|
| Z | Nonreparable item. When unserviceable, condemn and dispose at the level indicated in position 3. |
| O | Reparable item. When uneconomically reparable, condemn and dispose at organizational level. |
| F | Reparable item. When uneconomically reparable, condemn and dispose at the direct support level. |
| H | Reparable item. When uneconomically reparable, condemn and dispose at the general support level. |
| D | Reparable item. When beyond lower level repair capability, return to depot. Condemnation and disposal not authorized below depot level. |

| <i>Recoverability Codes</i> | <i>Definition</i> |
|-----------------------------|--|
| L | Reparable item. Repair, condemnation, and disposal not authorized below depot/specialized repair activity level. |

| <i>Recoverability Codes</i> | <i>Definition</i> |
|-----------------------------|---|
| A | Item requires special handling or condemnation procedures because of specific reasons (i.e., precious metal content, high dollar value, critical material, or hazardous material). Refer to appropriate manuals/directives for specific instructions. |
| c. | <i>National Stock Number.</i> Indicates the National stock number assigned to the item and which will be used for requisitioning. |
| d. | <i>Federal Supply Code for Manufacturer (FSCM).</i> The FSCM is a 5-digit numeric code listed in SB 708-42 which is used to identify the manufacturer, distributor, or Government agency, etc. |
| e. | <i>Part Number.</i> Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications, standards, and inspection requirements to identify an item or range of items. |

NOTE

When a stock numbered item is requisitioned, the item received may have a different part number than the part being replaced.

- f. *Description.* Indicates the Federal item name and, if required, a minimum description to identify the item.
- g. *Unit of Measure (U/M).* Indicates the standard of the basic quantity of the listed item as used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in, pr, etc). When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.

- h. *Quantity Incorporated in Unit.* Indicates the quantity of the item used in the breakout shown on the illustration figure, which is prepared for a functional group, subfunctional group, or an assembly. A "V" appearing in this column in lieu of a quantity indicates that no specific quantity is applicable, (e.g., shims, spacers, etc).

C-4. SPECIAL INFORMATION.

- a. Usable on codes are shown in description column. Uncoded items are applicable to all models.
- b. Detailed manufacturing instructions for items source coded to be manufactured or fabricated are found in Appendix E of this manual. Bulk materials required to manufacture items are listed in the bulk material group of this appendix.
- c. Action change codes indicated in the left hand margin of the listing page denote the following:
 - N Indicates an added item.
 - C Indicates a change in data.
 - R Indicates a change in NSN only.

C-5. HOW TO LOCATE REPAIR PARTS.

- a. When National Stock Number or Part Number is Unknown:
 - (1) *First.* Using the table of contents determine the functional group within which the item belongs. This is necessary since illustrations are prepared for functional groups, and listings are divided into the same groups.
 - (2) *Second.* Find the illustration covering the functional group to which the item belongs.
 - (3) *Third.* Identify the item on the illustration and note the illustration figure and item number of the item.
 - (4) *Fourth.* Using the Repair Parts Listing, find the figure and item number noted on the illustration.

- b. When National Stock Number or Part Number is Known:

- (1) *First.* Using the Index of National Stock Numbers and Part Numbers, find the pertinent National stock number or part number. This index is in NIIN sequence followed by a list of part numbers in alphameric sequence, cross-referenced to the illustration figure number and item number.
- (2) *Second.* After finding the figure and item number, locate the figure and item number in the repair parts list.

ABBREVIATIONS.

| Abbreviation | Explanation |
|--------------|------------------------|
| CFM | cubic feet per minute |
| dia | diameter |
| hd | head |
| hex | hexagon |
| in. | inch |
| id | inside diameter |
| lg | long |
| MFG | manufactured |
| mtg | mounting |
| NPS | National Pipe Standard |
| nom | nominal |
| no. | number |
| oa. | overall |
| od | outside diameter |
| porm | plus or minus |
| PSI | pounds per square inch |
| thk | thick |
| thd | thread |
| UNC | United National Coarse |
| UNF | United National Fine |
| w/ | with |

Section II REPAIR PARTS LIST




Figure C-1. M14 protective entrance

ARA 81-0034

| (1) ILLUSTRATION | | (2) | (3) | (4) | (5) | (6) DESCRIPTION | (7) | (8) QTY INC IN UNIT |
|------------------------------------|-------------------|-------------|-----------------------------|-------|---------------------|---|------|---------------------------------|
| (1) FIG NO | (2) ITEM NO | SPR CODE | NATIONAL STOCK NUMBER | FSCM | PART NUMBER | USABLE ON CODE | UNIT | |
| GROUP 0100 M14 PROTECTIVE ENTRANCE | | | | | | | | |
| E5-19 6201 30 | | | | | | | | |
| C-1 | 1 | PA000 | 4240-01-103-5521 | 81361 | E5-19-6201 30 | ENTRANCE, PROTECTIVE PRESSURIZED M14 | EA | 1 |
| C-1 | 2 | PA02Z | 5305-00-179-8946 | 96906 | MS51849-66 | SCREW, MACHINE HEX HD, NO. 10-32 UNF-2A, 3/4 IN. LG. | EA | 7 |
| C-1 | 3 | PA02Z | 5310-00-045-3296 | 96906 | MS35338-43 | WASHER, LOCK SPRING, NO. 10 NOM SIZE. | EA | 1 |
| C-1 | 4 | PA0FF | 4240-01-115-0996 | 81361 | E5-19-6641 | CONTROL MODULE, PROTECTIVE ENTRANCE | EA | 1 |
| C-1 | 5 | PA02Z | 4730-01-050-7540 | 30327 | KF03-04RV | ADAPTER, STRAIGHT, PIPE TO HOSE. | EA | 1 |
| C-1 | 6 | MO02Z | | 81361 | E5-19-6641-74 | HOSE, NONMETALLIC, LOW PRESSURE MFD FROM 4720-00-065-8602 | EA | 1 |
| C-1 | 7 | PA02Z | 4730-01-017-5119 | 30327 | KF03-02P9 | ADAPTER, STRAIGHT, PIPE TO HOSE | EA | 1 |
| C-1 | 8 | PA02Z | 5330-00-250-0236 | 96906 | MS29513-024 | PACKING, PREFORMED. | EA | 1 |
| C-1 | 9 | PA02Z | 9905-01-068-2368 | 81361 | 5-19-6657 | PLATE, INSTRUCTION NO STEP | EA | 1 |
| C-1 | 10 | PA000 | 5340-01-048 6327 | 81361 | C5-19-6145 | CAP, PROTECTIVE, DUST AND MOISTURE SEAL | EA | 2 |
| C-1 | 11 | PA02Z | 5305-00-115-9934 | 96906 | MS51849-55 | SCREW, MACHINE HEX HD, STL, 8-32 UNC-2A, 5/8 IN. LG. | EA | 3 |
| C-1 | 12 | PA02Z | 5310-00-765-3197 | 96906 | MS27183-41 | WASHER, FLAT .168 IN. ID .438 IN. OD .049 IN. THK | EA | 5 |
| C-1 | 13 | A0000 | | | CL-2-FANDCL-2-C-8.0 | CABLE, SUPPORT. | EA | 2 |
| C-1 | 14 | PA02Z | 4030-00-878-R693 | 99862 | CL2F | FERRULE, WIRE ROPE. | EA | 4 |
| C-1 | 15 | MO02Z | | 99862 | CL-2-C-8.0 | CABLE, NYLON 8 IN. LG. MFD FROM 4010-00-069-518C. | EA | 2 |
| C-1 | 16 | XA02Z | | 81361 | C5-19-6309 | CAP, RUBBER | EA | 2 |
| C-1 | 17 | PA02Z | 4730-00-908-6294 | 96906 | MS35842-16 | CLAMP HOSE 4-1/8 TO 7 IN DIA RANGE | EA | 2 |
| C-1 | 18 | PA02Z | 5310-00-811-3494 | 96906 | MS21044N08 | NUT, SELF-LOCKING, HEXAGON NO. 8-32 UNJC-1B. | EA | 1 |
| C-1 | 19 | PA02Z | 9905-01-049-1385 | 81361 | C5-19-6175 | PLATE, INSTRUCTION PARTIAL LEGEND OPENING PROCEDURE. | EA | 1 |
| C-1 | 20 | PA02Z | 9905-01-128-5825 | 81361 | C5-19-6316-13 | PLATE, IDENTIFICATION ENTRANCE, PROTECTIVE, PRESSURIZED, COLLAPSIBLE, M14. | EA | 1 |
| C-1 | 21 | PA02Z | 9905-01-048-2790 | 81361 | 05-19-6238 | PLATE, INSTRUCTION CAUTION DO NOT ENTER WHEN PROTECTIVE ENTRANCE IS OCCUPIED. | EA | 1 |
| C-1 | 22 | PA02Z | 5305-00-115-9406 | 96906 | MS51849-53 | SCREW, MACHINE HEX HD, STL, 8-32 UNC-2A X .38 IN LG. | EA | 3 |
| C-1 | 23 | PA02Z | 5310-00-045-3299 | 96906 | MS35338-42 | WASHER, LOCK SPRING, NO 8. | EA | 3 |
| C-1 | 24 | PA02Z | 4240-01-049-0804 | 81361 | C5-19-6236 | COVER, PROTECTIVE, TUBING CONNECTION | EA | 1 |
| C-1 | 25 | PA02Z | 5310-00-897-6981 | 96906 | MS35691-32 | NUT, PLAIN, HEXAGON JAM 7/16-20UNF-2B. | EA | 1 |
| C-1 | 26 | PA02Z | 4730-01-067-9232 | 81361 | C5-19-6654 | ADAPTER, PIPE TO TUBE 1/4NPS, 7/16-20UNF-2A. | EA | 1 |
| C-1 | 27 | PA02Z | 5310-00-928-9821 | 96906 | MS24679-2 | NUT, PLAIN, CAP NO. 8-32 UNC-2B. | EA | 3 |
| C-1 | 28 | PA02Z | 5935-00-490 5580 | 96906 | MS7181 14N | COVER, ELECTRICAL CONNECTOR. | EA | 1 |
| C-1 | 29 | PA02Z | 5310-00-435-8987 | 96906 | MS3186-43 | NUT, PLAIN, HEXAGON 1-20UNEF-2B. | EA | 1 |




Figure C-2. Protective entrance control module

ARA 81-0035

| (1) ILLUSTRATION | | (2) | (3) | (4) | (5) | (6) DESCRIPTION | (7) | (8) |
|---------------------|-------------------|-------------|-----------------------------|-------|------------------------|--|-----|--------------------------|
| (a) FIG NO | (b) ITEM NO | SMR CODE | NATIONAL STOCK NUMBER | FSCM | PART NUMBER | USABLE ON CODE | U M | QTY INC IN UNIT |
| | | | | | | GROUP 0110 PROTECTIVE ENTRANCE CONTROL MODULE C5 19 6641 | | |
| C-2 | 1 | PAQZZ | 5355-00-R21 5225 | 79919 | K35B1 | MODULE | EA | 1 |
| C-2 | 2 | PAQZZ | 6240-00-763-7744 | 96906 | MS25237-387 | LAMP INCANDESCENT TRANSPARENT WHITE, | FA | 2 |
| C-2 | 3 | XAOZZ | | 96906 | MS25041-B LENS ONLY | LENS..... | EA | 1 |
| C-2 | 4 | XAOZZ | | 04426 | 44-601 | LIGHT. MODULE..... | EA | 1 |
| C-2 | 5 | PAQZZ | 6240-00-155-7784 | 96906 | MS35478-307 | LAMP, INCANDESCENT TRANSPARENT, WHITE LIGHT EMITTED..... | EA | 1 |
| C-2 | 6 | PAQZZ | 6240-00-155-7932 | 96906 | MS25235-R311 | LAMP, INCANDESCENT TRANSLUCENT, RED LIGHT EMITTED..... | EA | 1 |
| C-2 | 7 | PAQZZ | 5330-00-143-8571 | 96906 | MS25358-6 | GASKET DOME LIGHT..... | FA | 1 |
| C-2 | 8 | PAQZZ | 6220-00-283-9732 | 96906 | MS25358-4 | LENS, LIGHT..... | FA | 1 |
| C-2 | 9 | XAOZZ | | 96906 | MS25358-5 | RETAINER LIGHT..... | EA | 1 |
| C-2 | 10 | PAQZZ | 5305-00-889-2999 | 96906 | MS35206-217 | SCREW, MACHINE PAN HD, NO. 4-40 UNC-2A 1/2 IN. LG..... | FA | 6 |
| C-2 | 11 | PAQZZ | 9705-01-128-5826 | 81361 | C5-19-6316-B | PLATE, IDENTIFICATION CONTROL MODULE, PROTECTIVE ENTRANCE .. | EA | 1 |




Figure C-2. Protective entrance control module

ARA 81-003

| (1) ILLUSTRATION | | (2) SMR CODE | (3) NATIONAL STOCK NUMBER | (4) FSCM | (5) PART NUMBER | (6) DESCRIPTION | (7) USABLE ON CODE | (8) QTY INC IN UNIT |
|---------------------|-------------------|--------------------|------------------------------------|-------------|------------------------|--|-----------------------|---------------------------------|
| (a) FIG NO | (b) ITEM NO | | | | | | | |
| | | | | | | GROUP 0110 PROTECTIVE ENTRANCE CONTROL MODULE E5 19 6641 | | |
| C-2 | 1 | PA0ZZ | 5355-00-821 5223 | 79919 | K3581 | KNOB | EA | 1 |
| C-2 | 2 | PA0ZZ | 6240-00-763-7744 | 96906 | MS25237-387 | LAMP INCANDESCENT TRANSPARENT WHITE | EA | 3 |
| C-2 | 3 | XA0ZZ | | 96906 | MS25041-B LENS ONLY | LENS | EA | 1 |
| C-2 | 4 | XA0ZZ | | 04426 | 44-601 | LIGHT, MODULE | EA | 1 |
| C-2 | 5 | PA0ZZ | 6240-00-155-7784 | 96906 | MS35478-307 | LAMP, INCANDESCENT TRANSPARENT, WHITE LIGHT EMITTED | EA | 1 |
| C-2 | 6 | PA0ZZ | 6240-00-155-7932 | 96906 | MS25235-R311 | LAMP, INCANDESCENT TRANSLUCENT, RED LIGHT ONLY | EA | 1 |
| C-2 | 7 | PA0ZZ | 5330-00-143-8571 | 96906 | MS25358-6 | CASKET DOME LIGHT | EA | 1 |
| C-2 | 8 | PA0ZZ | 6220-00-283-9732 | 96906 | MS25358-4 | LENS, LIGHT | EA | 1 |
| C-2 | 9 | XA0ZZ | | 96906 | MS25358-5 | PETAINER LIGHT | EA | 1 |
| C-2 | 10 | PA0ZZ | 5305-00-889-2999 | 96906 | MS35206-217 | SCREW, MACHINE PAN HD, NO. 4-40 UNC-2A 1/2 IN. LG. | EA | 6 |
| C-2 | 11 | PA0ZZ | 9705-01-128-5826 | 81361 | C5-19-6316-B | PLATE, IDENTIFICATION CONTROL MODULE, PROTECTIVE ENTRANCE. . | EA | 1 |




Figure C-3. M59 gas-particulate filter unit

ARA 81-0

| (1) ILLUSTRATION | | (2) | (3) | (4) | (5) | (6) DESCRIPTION | (7) | (8) QTY INC IN UNIT |
|--|------------|-------------|-----------------------------|-------|----------------|---|-----|---------------------------------|
| FIG NO | ITEM NO | S&R CODE | NATIONAL STOCK NUMBER | FSCM | PART NUMBER | USABLE ON CODE | U P | |
| GROUP 0200 M59 GAS PARTICULATE FILTER UNIT | | | | | | | | |
| E5-19-6699 | | | | | | | | |
| C-3 | 1 | PAQDD | 4240-00-237-0223 | 81361 | E5-19-6699 | FILTER UNIT, GAS-PARTICULATE 2 FILTER, M59..... | EA | 1 |
| C-3 | 2 | PAQZZ | 9905-01-128-5824 | 81361 | C5-19-6316-14 | PLATE IDENTIFICATION FILTER UNIT, GAS-PARTICULATE, 2 FILTER M59..... | EA | 1 |
| C-3 | 3 | PADFF | 4240-01-057-3378 | 81361 | E5-19-6376 | CONTROL MODULE UNIT..... | EA | 1 |
| C-3 | 4 | PAQZA | 4240-01-067-5609 | 81361 | S-19-6718 | FILTER SET, GAS PARTICULATE..... | EA | 2 |
| C-3 | 5 | PAQZA | 4240-01-066-3266 | 81361 | D5-19-6262 | FILTER, PARTICULATE..... | EA | 2 |
| C-3 | 6 | XAQZA | | 81361 | D5-19-6368 | FILTER, GAS..... | EA | 2 |
| C-3 | 7 | PADFF | 4240-01-068-8645 | 81361 | E5-19-6387 | POWER DISTRIBUTION UNIT, GAS PARTICULATE FILTER SYSTEM .. | EA | 1 |
| C-3 | 8 | MQDZZ | | 81361 | E5-19-6699-7 | TUBING NONMETALIC 1/4 IN. OD, GREEN RPD FROM 4720J10510716 | EA | 1 |
| C-3 | 9 | MQDZZ | | 81361 | E5-19-6699-6 | TUBING NONMETALIC 1/4 IN. OD, RED, RPD FROM 4720G09960381 | EA | 1 |
| C-3 | 10 | XBQFF | 4240-01-114-3213 | 81361 | E5-19-6308-20 | HOUSING UNIT, FAN-VALVE COLLECTOR, 2 FILTER..... | EA | 1 |




Figure C-4. Housing unit

ARA 81-0037

| (1) ILLUSTRATION | | (2) SMR CODE | (3) NATIONAL STOCK NUMBER | (4) FSC# | (5) PART NUMBER | (6) DESCRIPTION | (7) U.S. MIL. UNIT | (8) QTY. IN KIT |
|---------------------|--------------------|--------------------|------------------------------------|-------------|-----------------------|--|-----------------------|--------------------|
| (a) FIG NO. | (b) ITEM NO. | | | | | USABLE ON CODE | | |
| | | | | | | GROUP 0210 HOUSING UNIT | | |
| | | | | | | D5 19-6308-20 | | |
| C-4 | 1 | PA000 | 9340-01-048-6327 | 81361 | C5-19-6145 | CAP, PROTECTIVE, DUST AND MOISTURE SEAL | EA | 1 |
| -4 | 2 | PA0ZZ | 5305-00-115-9934 | 96906 | MS51849-55 | SCREW, MACHINE HEX HD, STL 8-32 UNF-2A X 5/8 IN. LG. | FA | 2 |
| C-4 | 3 | PA0ZZ | 5310-00-765-3197 | 96906 | MS27183-41 | WASHER, FLAT .180 IN. ID. .438 IN. OD. .049 IN. THK. | EA | 4 |
| C-4 | 4 | AD000 | | 99862 | CL-2-FANDCL-2-C-8.0 | CABLE SUPPORT..... | EA | 1 |
| C-4 | 5 | PA0ZZ | 4030-00-878-8693 | 99862 | CL2F | FERRULE, WIRE ROPE | EA | 2 |
| C-4 | 6 | MD0ZZ | | 99862 | CL-2-C-8 0 | CABLE NYLON, 8 IN. LG. MFD FROM 4010000695180 | EA | 1 |
| C-4 | 7 | XA0ZZ | | 81361 | C5-19-6309 | CAP, RUBBER..... | EA | 1 |
| C-4 | 8 | PA0ZZ | 4730-00-908-6294 | 96906 | MS35842-16 | CLAMP, HOSE 4-1/8 TO 7 IN. DIA RANGE | EA | 1 |
| C-4 | 9 | PA0ZZ | 5310-00-811-3494 | 96906 | MS21044N08 | NUT SELF-LOCKING, HEXAGON 8-32 UNF-3B..... | FA | 2 |
| C-4 | 10 | PA0DD | 4140-01-107-2246 | 81361 | E5-19-6317-10 | FAIR VALVE AXIAL 400 CFM..... | EA | 1 |
| C-4 | 11 | PA0ZZ | 5310-00-809-4058 | 96906 | MS27183-10 | WASHER, FLAT .281 IN. ID. .625 IN. OD. .065 IN. THK. | EA | 6 |
| C-4 | 12 | PA0ZZ | 5305-00-068-0511 | 96906 | MS90727-6 | SCREW, CAP HEXAGON HEAD 1/4-28UNF-2A, 3/4 IN LG..... | EA | 6 |
| C-4 | 13 | PA0ZZ | 5305-00-824-7363 | 80205 | NAS1096-3-12 | SCREW, MACHINE HEX HD .190-32 UNF-1A X .750 LG..... | EA | 8 |
| C-4 | 14 | PA0ZZ | 5310-00-014-5850 | 96906 | MS27183-42 | WASHER, FLAT .219 IN. ID. .500 IN. OD. .049 IN. THK..... | EA | 8 |
| C-4 | 15 | PA0FF | 4240-01-095-1493 | 81361 | E5-19-6136 | VALVE AIRFLOW..... | EA | 1 |
| C-4 | 16 | PA0ZZ | 5330-01-088-4442 | 81361 | 5-19-6348 | GASKET VALVE..... | FA | 1 |
| C-4 | 17 | PA0ZZ | 5310-00-877-5797 | 96906 | MS21044N3 | NUT, SELF-LOCKING, HEXAGON, NO. 10-32 UNF-3B | EA | 8 |
| C-4 | 18 | XD0ZZ | 4240-01-105-5393 | 81361 | E5-19-6121 | HOUSING, GAS-PARTICULATE, 2 FILTER | EA | 1 |
| C-4 | 19 | PA0ZZ | 5330-01-069-9824 | 81361 | C5-19-5687-2 | SEAL, RUBBER SPECIAL SHAPED SECTION. | EA | 1 |
| C-4 | 20 | XD0ZZ | | 81361 | E5-19-6128 | COVER, ACCESS, OUTER..... | EA | 1 |
| C-4 | 21 | PA0ZZ | 5310-00-080-6004 | 96906 | MS27183-14 | WASHER, FLAT .406 IN. ID .812 IN. OD. .065 IN. THK. | EA | 6 |
| C-4 | 22 | PA0ZZ | 5310-00-187-2400 | 89044 | AN960PD616 | WASHER, FLAT .390 IN. ID. .625 IN. OD. .063 IN. THK. | EA | 6 |
| C-4 | 23 | PA0ZZ | 5305-00-269-3240 | 96906 | MS90727-64 | SCREW, CAP, HEXAGON HEAD 3/8-24 UNF-2A, 1-1/2 IN LG. | EA | 6 |
| C-4 | 24 | XD0ZZ | | 81361 | D5-19-6260 | COVER, INNER..... | EA | 1 |
| C-4 | 25 | PA0ZZ | 5330-01-068-0515 | 81361 | C5-19-5687-1 | SEAL, RUBBER SPECIAL SHAPED SECTION | FA | 1 |
| C-4 | 26 | PA0ZZ | 9905-01-067-8634 | 81361 | D5-19-6114 | PLATE, INSTRUCTION WARNING TORQUE OUTER COVER BOLTS 180 TO 200 INCH POUNDS..... | EA | 1 |
| C-4 | 27 | PA0ZZ | 9905-01-066-3084 | 81361 | C5-19-6135 | PLATE, INSTRUCTION WARNING DO NOT REMOVE COVERS TO SERVICE COMPONENTS AFTER TOXIC EXPOSURE WITHOUT OBSERVING PROPER HANDLING PROCEDURES..... | EA | 1 |
| C-4 | 28 | PA0ZZ | 9905-01-050-7557 | 81361 | D5-19-6133 | PLATE, INSTRUCTION WARNING TIGHTEN UNTIL SLEEVE IS FLUSH WITH TOP SURFACE..... | EA | 1 |
| C-4 | 29 | PA0ZZ | 5305-00-180-4966 | 96906 | MS51849-64 | SCREW, MACHINE HEX HD NO. 10-32UNF-2A 1/2 IN. LG..... | EA | 1 |
| C-4 | 30 | PA0ZZ | 5340-01-032-6929 | 96906 | MS9352-06 | CLAMP, LOOP CUSHIONED 7/16 IN. NOM TUBE OD. | FA | 1 |
| C-4 | 31 | PA0ZZ | 4730-00-817-1891 | 30327 | 261P1-4 | NUT, TUBE COUPLING 1/4 IN TUBE OD, 3/16-20 THD SIZE W/4 FEWFE. | EA | 2 |
| C-4 | 32 | PA0ZZ | 5365-01-057-7379 | 81361 | D5-19-6347 | BUSHING, RUBBER..... | EA | 1 |
| C-4 | 33 | PA0ZZ | 5310-00-081-4219 | 96906 | MS27183-12 | WASHER, FLAT .344 IN. ID .698 IN. OD. .065 IN. THK..... | EA | 8 |
| C-4 | 34 | PA0ZZ | 5305-00-051-4075 | 96906 | MS90727-33 | SCREW, CAP, HEXAGON HEAD 5/16 UNF-2A, 7/8 IN. LG..... | EA | 8 |
| C-4 | 35 | PA0ZZ | 4730-01-108-2625 | 81361 | D5-19-6401-20 | TEE, FLANGE TO HOSE..... | EA | 1 |




Figure C-5. Airflow valve

| (1) ILLUSTRATION | | (2) | (3) | (4) | (5) | (6) | (7) | (8) |
|---------------------|-------------------|-------------|-----------------------------|-------|-------------------------|--|----------------|--------------------------|
| (a) FIG NO | (b) ITEM NO | SHR CODE | NATIONAL STOCK NUMBER | FSCM | PART NUMBER | DESCRIPTION | USABLE ON CODE | QTY INC IN UNIT |
| | | | | | | GROUP 0212 AIRFLOW VALVE E5-19-6136 | | |
| -5 | 1 | PAQZZ | 9905-01-065-9382 | 81361 | C5-19-6149 | PLATE, IDENTIFICATION AIRFLOW VALVE, | EA | 1 |
| -5 | 2 | PAQZZ | 9905-01-051-0186 | 81361 | B5-19-6147 | PLATE, INSTRUCTION TO SHELTER..... | EA | 1 |
| -5 | 3 | PAQZZ | 9905-01-050-7556 | 81361 | B5-19-6148 | PLATE, INSTRUCTION TO PROT ENT..... | EA | 1 |
| -5 | 4 | PAQZZ | 4730-00-908-6294 | 96906 | MS35842-16 | CLAMP, HOSE 4-1/8 TO 7 IN. DIA RANGE..... | EA | 2 |
| -5 | 5 | PAQZZ | 5310-00-811-3494 | 96906 | MS21044N08 | NUT, SELF-LOCKING, HEXAGON HD, 8-32 UNC-3B..... | EA | 3 |
| -5 | 6 | PAQZZ | 5310-00-765-3197 | 96906 | MS27183-41 | WASHER, FLAT .188 IN. ID. .438 IN. OD. .049 IN. THK..... | EA | 6 |
| -5 | 7 | XAQZZ | | 81361 | C5-19-6309 | CAP, RUBBER..... | EA | 2 |
| 5 | 8 | AQ000 | | 99862 | CL-2-FANDCL-2-C- B.O | CABLE, SUPPORT..... | EA | 2 |
| 5 | 9 | PAQZZ | 4030-00-878-8692 | 99862 | CL2F | FERRULE, WIRE ROPE..... | EA | 4 |
| 5 | 10 | HQ027 | | 99062 | CL-2-C-B.O | CABLE, NYLON 8 IN. LG. MFD FROM 4010 00-069-5180 | EA | 2 |
| 5 | 11 | PAQZZ | 5305-00-115-9934 | 96906 | MS51849-55 | SCREW, MACHINE HEX HD ND, 8-32 UNC-2A 5/8 IN. LG. | EA | 2 |
| 5 | 12 | PAQ00 | 5340-01-048-6327 | 81361 | C5-19-6145 | CAP, PROTECTIVE, DUST AND MOISTURE SEAL | EA | 2 |
| 5 | 13 | PAQZZ | 5305-00-157-5621 | 96906 | MS51849-56 | SCREW, MACHINE HEX HD, ND, 8-32 UNC-2A 3/4 IN. LG. | EA | 1 |




Figure C-6. Power distribution panel

ARA

| (1) ILLUSTRATION | | (2) | (3) | (4) | (5) | (6) | (7) | (8) |
|---------------------|-------------------|-------------|-----------------------------|-------|----------------------------|---|-----|--------------------------|
| (a) FIG NO | (b) ITEM NO | SMR CODE | NATIONAL STOCK NUMBER | FSCM | PART NUMBER | DESCRIPTION USABLE ON CODE | U M | QTY INC IN UNIT |
| | | | | | | GROUP 0221 POWER DISTRIBUTION PANEL E5-19-6391 | | |
| C-6 | 1 | PADZZ | 6240-00-892-1420 | 81349 | H15098/11-001 | LAMP, GLOW..... | EA | 1 |
| C-6 | 2 | XADZZ | | 07137 | PTL-A113-C7A1 LENS ONLY | LENS | EA | 1 |
| C-6 | 3 | PADZZ | 9903-01-065-3065 | 81361 | C5-19-6316-6 | PLATE IDENTIFICATION POWER DISTRIBUTION UNIT..... | EA | 1 |
| C-6 | 4 | PADZZ | 4730-00-817-1891 | 30327 | 261P1-4 | NUT, TUBE COUPLING 1/4 IN. TUBE OD. 3/8-24 THD SIZE, W/SLEEVE | EA | 2 |




Figure C-7. Compartment control module

ARA 81-004

| (1) ILLUSTRATION | | (2) | (3) | (4) | (5) | (6) | (7) | (8) |
|---------------------|-------------------|-------------|-----------------------------|-------|------------------------|--|-----|--------------------------|
| (1) FIG NO | (2) ITEM NO | SNR CODE | NATIONAL STOCK NUMBER | FSCM | PART NUMBER | DESCRIPTION USABLE ON CODE | U M | QTY INC IN UNIT |
| | | | | | | GROUP 0230 COMPARTMENT CONTROL MODULE E5-19-6376 | | |
| C-7 | 1 | PA0ZZ | 6240-00-763-7744 | 96906 | MS25237-387 | LAMP, INCANDESCENT TRANSPARENT, WHITE LIGHT EMITTED..... | EA | 8 |
| C-7 | 2 | XA0ZZ | | 04426 | 44-601 | LIGHT MODULE..... | EA | |
| C-7 | 3 | XA0ZZ | | 96906 | MS25041-8 LENS ONLY | LENS..... | EA | 2 |




Figure C-8. M265 installation kit

ARA 81-0041

| (1) ILLUSTRATION | | (2) | (3) | (4) | (5) | (6) | (7) | (8) |
|---------------------|--------|----------|-----------------------|-------|-----------------|---|----------------|-----------------|
| FIG NO | REV NO | SMR CODE | NATIONAL STOCK NUMBER | FSCM | PART NUMBER | DESCRIPTION | USABLE DN CODE | QTY INC IN UNIT |
| | | | | | | GROUP 0300 M265 INSTALLATION KIT | | |
| | | | | | | PL 5-19-6707 | | |
| C-B | 1 | PAQZZ | 4730-01-049-0805 | 81361 | C5-19-6182 | COUPLING, AIR DUCT,..... | EA | 1 |
| C-B | 2 | PAQZZ | 4240-01-052-3783 | 81361 | C5-19-6180 | HOLDER, STORAGE, AIR DUCT..... | EA | 8 |
| C-B | 3 | PAQZZ | 4240-01-061-7233 | 81361 | E5-19-5908 | FRAME, INTERFACE, ENTRANCE..... | EA | 1 |
| C-B | 4 | PAQZZ | 4730-01-134-6603 | 11645 | B-4-MHC-3S | ADAPTER, STRAIGHT, PIPE 1/4 PIPE X 3/16 ID. HOSE..... | EA | 1 |
| C-B | 5 | PAQZZ | 4240-01-131-3206 | 81361 | E5-19-6686 | ADAPTER, AIR DUCT FOUR DUCT..... | EA | 1 |
| C-B | 6 | PAQZZ | 5310-00-088-0553 | 96906 | MS21044H5 | NUT, SELF-LOCKING, HEXAGON 5/16-24UNF-3D..... | EA | 4 |
| C-B | 7 | MOQZZ | | 81361 | PL 5-19-6707-13 | HOSE, LOW PRESSURE, MFD FROM 4720000658682..... | EA | 1 |
| C-B | 8 | PAQZZ | 5310-00-080-6004 | 96906 | MS27183-14 | WASHER, FLAT STEEL, .406 IN. ID. .812 IN. O.D. .065 IN. THK..... | EA | 8 |
| C-B | 9 | PAQZZ | 5306-00-543-4436 | 96906 | MS35308-337 | BOLT, MACHINE HEX HD. STEEL, 5/16-24 UNF-2A X 1.375 LG..... | EA | 4 |
| C-B | 10 | PAQZZ | 5305-00-680-4262 | 96906 | MS35308-360 | SCREW, CAP, HEXAGON HEAD 3/8-24UNF-2A X 1.000 IN. LG..... | EA | 8 |
| C-B | 11 | PAQZZ | 4720-01-074-9220 | 81361 | C5-19-6181-10 | HOSE, AIR DUCT 6 IN. ID 72 IN. O/A LG..... | EA | 9 |
| C-B | 12 | PAQZZ | 5310-00-081-4219 | 96906 | MS27183-12 | WASHER, FLAT .344 IN. ID. .688 IN. OD .065 IN. THK..... | EA | 4 |
| C-B | 13 | PAQZZ | 4720-01-106-4602 | 81361 | B5-19-6716 | HOSE, NONMETALLIC 6.000 IN. ID. 4.000 IN. LG 50 PSI..... | EA | 1 |
| C-B | 14 | PAQZZ | 4240-01-111-4645 | 81361 | C5-19-6162-20 | CABLE ASSEMBLY, SPECIAL PURPOSE ELECTRICAL 240 IN. NOM LG. EXCLUDING TERMINATIONS..... | EA | 1 |
| C-B | 15 | PAQZZ | 4240-01-114-2776 | 81361 | C5-19-6712-10 | CABLE ASSEMBLY, SPECIAL PURPOSE, ELECTRICAL 72 IN NOM. LG., EXCLUDING TERMINATIONS..... | EA | 1 |
| C-B | 16 | PAQZZ | 4240-01-067-8376 | 81361 | 5-19-6170-10 | CABLE ASSEMBLY, SPECIAL PURPOSE ELECTRICAL 54 IN. NOM LG., EXCLUDING TERMINATIONS..... | EA | 1 |
| C-B | 17 | PAQZZ | 4730-00-908-6294 | 96906 | MS35842-16 | CLAMP, HOSE LOW PRESSURE..... | EA | 2 |
| C-B | 18 | PAQZZ | 4240-01-049-0804 | 81361 | C5-19-6236 | COVER, PROTECTIVE TUBING CONNECTION..... | EA | 1 |
| C-B | 19 | PAQZZ | 4240-01-129-0836 | 81361 | D5-19-6290-20 | STAND, FILTER UNIT..... | EA | 1 |

| (1) ILLUSTRATION | | (2) | (3) | (4) | (5) | (6) | (7) | (8) |
|--------------------------|-------------------|-------------|-----------------------------|-------|----------------|---|------|--------------------------|
| (A) FIG NO | (B) ITEM NO | SHR CODE | NATIONAL STOCK NUMBER | FSCM | PART NUMBER | DESCRIPTION USABLE ON CODE | UNIT | QTY INC IN UNIT |
| GROUP 0500 BULK SUPPLIES | | | | | | | | |
| BULK | | PA77Z | 4010-00-069-5180 | 99862 | CL2C | CABLE, NYLON COVERED NYLON COVERED..... | FT | 4 |
| BULK | | PA02Z | 4720-00-065-8682 | 30327 | C403 | HOSE, NONMETALLIC LOW PRESSURE, RUBBER, 3/16 IN. NOM. ID., | FT | 3 |
| BULK | | PA02Z | 4720-00-996-0381 | 30327 | 44P RED | TUBING, NONMETALLIC PLASTIC, 1/4 IN. OD, .040 IN. WALL THK, RED..... | FT | 5 |
| BULK | | PA02Z | 4720-01-053-0316 | 30327 | 44P GREEN | TUBING, NONMETALLIC PLASTIC, 1/4 IN. OD, .040 IN. WALL THK, GREEN..... | FT | 5 |

Section III SPECIAL TOOLS AND EQUIPMENT LIST

Not applicable

Section IV NATIONAL STOCK NUMBER AND PART NUMBER INDEX

| STOCK NUMBER | FIGURE NO. | ITEM NO. | STOCK NUMBER | FIGURE NO. | ITEM NO. |
|------------------|------------|----------|------------------|------------|----------|
| 5310-00-014-5850 | C-4 | 14 | 4730-00-908-6294 | C-B | 17 |
| 5310-00-045-3296 | C-1 | 3 | 5310-00-928-9821 | C-1 | 27 |
| 5310-00-045-3299 | C-1 | 23 | 5935-00-990-5580 | C-1 | 28 |
| 5305-00-051-4075 | C-4 | 34 | 4720-00-996-0381 | BULK | |
| 4720-00-065-8682 | BULK | | 4730-01-017-5119 | C-1 | 7 |
| 5305-00-068-0513 | C-4 | 12 | 5340-01-032-6929 | C-4 | 30 |
| 4010-00-069-5180 | BULK | | 9905-01-048-2790 | C-1 | 21 |
| 5310-00-080-6004 | C-4 | 21 | 5340-01-048-6327 | C-1 | 10 |
| 5310-00-080-6004 | C-8 | 8 | 5340-01-048-6327 | C-4 | 1 |
| 5310-00-081-4219 | C-4 | 33 | 5340-01-048-6327 | C-5 | 12 |
| 5310-00-081-4219 | C-8 | 12 | 4240-01-049-0804 | C-1 | 24 |
| 5310-00-088-0553 | C-8 | 6 | 4240-01-049-0804 | C-8 | 18 |
| 5305-00-115-9406 | C-1 | 22 | 4730-01-049-0805 | C-8 | 1 |
| 5305-00-115-9934 | C-1 | 11 | 9905-01-049-1385 | C-1 | 19 |
| 5305-00-115-9934 | C-4 | 2 | 4730-01-050-7540 | C-1 | 5 |
| 5305-00-115-9934 | C-5 | 11 | 9905-01-050-7556 | C-5 | 3 |
| 5305-00-143-8571 | C-2 | 7 | 9905-01-050-7557 | C-4 | 28 |
| 240-00-155-7784 | C-2 | 5 | 9905-01-051-0186 | C-5 | 2 |
| 240-00-155-7932 | C-2 | 6 | 4240-01-052-3783 | C-8 | 2 |
| 5305-00-157-5621 | C-5 | 13 | 4720-01-053-0316 | BULK | |
| 5305-00-179-8946 | C-1 | 2 | 4240-01-055-1493 | C-4 | 15 |
| 5305-00-180-4966 | C-4 | 29 | 4240-01-057-3378 | C-3 | 3 |
| 5310-00-187-2400 | C-4 | 22 | 5365-01-057-7379 | C-4 | 32 |
| 240-00-237-0223 | C-3 | 1 | 4240-01-061-7233 | C-8 | 3 |
| 5305-00-250-0236 | C-1 | 6 | 9905-01-065-3065 | C-6 | 3 |
| 5305-00-269-3240 | C-4 | 23 | 9905-01-065-9382 | C-5 | 1 |
| 220-00-283-9732 | C-2 | 8 | 9905-01-066-3084 | C-4 | 27 |
| 5310-00-435-8983 | C-1 | 29 | 4240-01-066-3266 | C-3 | 5 |
| 5305-00-543-4436 | C-6 | 9 | 4240-01-067-5605 | C-3 | 4 |
| 5305-00-680-4662 | C-8 | 10 | 4240-01-067-8376 | C-8 | 16 |
| 240-00-763-7744 | C-2 | 2 | 9905-01-067-8634 | C-4 | 26 |
| 240-00-763-7744 | C-7 | 1 | 4730-01-067-9232 | C-1 | 26 |
| 5310-00-765-3197 | C-1 | 12 | 5330-01-068-0515 | C-4 | 25 |
| 5310-00-765-3197 | C-4 | 3 | 9905-01-068-2368 | C-1 | 9 |
| 5310-00-765-3197 | C-5 | 6 | 4240-01-068-8645 | C-3 | 7 |
| 110-00-809-4058 | C-4 | 11 | 5330-01-069-9824 | C-4 | 19 |
| 110-00-811-3494 | C-1 | 15 | 4720-01-074-9220 | C-8 | 11 |
| 110-00-811-3494 | C-4 | 9 | 5330-01-086-4442 | C-4 | 16 |
| 110-00-811-3494 | C-5 | 5 | 4240-01-105-5393 | C-4 | 18 |
| 30-00-817-1891 | C-4 | 31 | 4240-01-105-5521 | C-1 | 1 |
| 30-00-817-1891 | C-6 | 4 | 4720-01-106-4602 | C-8 | 13 |
| 55-00-821-5225 | C-2 | 1 | 4140-01-107-2246 | C-4 | 10 |
| 05-00-824-7363 | C-4 | 13 | 4730-01-108-2625 | C-4 | 35 |
| 10-00-877-5797 | C-4 | 17 | 4240-01-111-4649 | C-8 | 14 |
| 30-00-878-8693 | C-1 | 14 | 4240-01-114-2976 | C-8 | 15 |
| 30-00-878-8693 | C-4 | 5 | 4240-01-114-3213 | C-3 | 10 |
| 30-00-878-8693 | C-5 | 9 | 4240-01-115-0996 | C-1 | 4 |
| 05-00-889-2999 | C-2 | 10 | 9905-01-128-5824 | C-3 | 2 |
| 40-00-892-4420 | C-6 | 1 | 9905-01-128-5825 | C-1 | 20 |
| 10-00-897-6081 | C-1 | 25 | 9905-01-128-5826 | C-2 | 11 |
| 30-00-908-6294 | C-1 | 17 | 4240-01-129-0836 | C-8 | 19 |
| 30-00-908-6294 | C-4 | E | 4240-01-131-5206 | C-8 | 5 |
| 30-00-908-6294 | C-5 | 4 | 4730-01-134-6603 | C-8 | 4 |

| FSCM | PART NUMBER | FIGURE NO. | ITEM NO. | FSCM | PART NUMBER | FIGURE NO. | ITEM NO. |
|-------|---------------------|------------|----------|-------|---------------|------------|----------|
| 88044 | AN960PD616 | C-4 | 22 | 81361 | C5-19-6135 | C-4 | 27 |
| 11649 | B-4-MHC-3S | C-8 | 4 | 81361 | C5-19-6145 | C-1 | 10 |
| 81361 | B5-19-6133 | C-4 | 28 | 81361 | C5-19-6145 | C-4 | 1 |
| 81361 | B5-19-6134 | C-4 | 26 | 81361 | C5-19-6145 | C-5 | 12 |
| 81361 | B5-19-6147 | C-5 | 2 | 81361 | C5-19-6149 | C-5 | 1 |
| 81361 | B5-19-6148 | C-5 | 3 | 81361 | C5-19-6162-20 | C-8 | 14 |
| 81361 | B5-19-6238 | C-1 | 21 | 81361 | C5-19-6175 | C-1 | 19 |
| 81361 | B5-19-6347 | C-4 | 32 | 81361 | C5-19-6180 | C-8 | 2 |
| 81361 | B5-19-6716 | C-8 | 13 | 81361 | C5-19-6181-10 | C-8 | 11 |
| 99862 | CL-2-C-8.0 | C-1 | 15 | 81361 | C5-19-6182 | C-8 | 1 |
| 99862 | CL-2-C-8.0 | C-4 | 6 | 81361 | C5-19-6236 | C-1 | 24 |
| 99862 | CL-2-C-8.0 | C-5 | 10 | 81361 | C5-19-6236 | C-8 | 18 |
| 99862 | CL-2-FANDCL-2-C-8.0 | C-1 | 13 | 81361 | C5-19-6309 | C-1 | 16 |
| 99862 | C1-2-FANDCL-2-C-8.0 | C-4 | 4 | 81361 | C5-19-6309 | C-4 | 7 |
| 99862 | CL-2-FANDCL-2-C-8.0 | C-5 | 8 | 81361 | C5-19-6309 | C-5 | 7 |
| 99862 | CL2C | BULK | | 81361 | C5-19-6316-13 | C-1 | 20 |
| 99862 | CL2F | C-1 | 14 | 81361 | C5-19-6316-14 | C-3 | 2 |
| 99862 | CL2F | C-4 | 5 | 81361 | C5-19-6316-6 | C-6 | 3 |
| 99862 | CL2F | C-5 | 9 | 81361 | C5-19-6316-8 | C-2 | 11 |
| 30327 | C403 | BULK | | 81361 | C5-19-6554 | C-1 | 26 |
| 81361 | C5-19-5687-1 | C-4 | 25 | 81361 | C5-19-6712-10 | C-8 | 15 |
| 81361 | C5-19-5687-2 | C-4 | 19 | 81361 | D5-19-6260 | C-4 | 24 |

11

| FSCM | PART NUMBER | FIGURE NO. | ITEM NO. | FSCM | PART NUMBER | FIGURE NO. | ITEM NO. |
|-------|---------------|------------|----------|-------|----------------|------------|----------|
| 81361 | D5-19-6262 | C-3 | 5 | 96906 | MS27183-41 | C-4 | 3 |
| 81361 | D5-19-6290-20 | C-8 | 19 | 96906 | MS27183-41 | C-5 | 6 |
| 81361 | D5-19-6368 | C-3 | 6 | 96906 | MS27183-42 | C-4 | 14 |
| 81361 | D5-19-6401-20 | C-4 | 35 | 96906 | MS29513-024 | C-1 | 8 |
| 81361 | E5-19-5908 | C-8 | 3 | 96906 | MS3181-14N | C-1 | 28 |
| 81361 | E5-19-6121 | C-4 | 18 | 96906 | MS3186-43 | C-1 | 29 |
| 81361 | E5-19-6128 | C-4 | 20 | 96906 | MS35206-217 | C-2 | 10 |
| 81361 | E5-19-6136 | C-4 | 15 | 96906 | MS35308-337 | C-8 | 9 |
| 81361 | E5-19-6201-50 | C-1 | 1 | 96906 | MS35309-360 | C-8 | 10 |
| 81361 | E5-19-6308-20 | C-3 | 10 | 96906 | MS35338-42 | C-1 | 23 |
| 81361 | E5-19-6317-10 | C-4 | 10 | 96906 | MS35338-43 | C-1 | 3 |
| 81361 | E5-19-6376 | C-3 | 3 | 96906 | MS35478-307 | C-2 | 5 |
| 81361 | E5-19-6387 | C-3 | 7 | 96906 | MS35691-32 | C-1 | 25 |
| 81361 | E5-19-6641 | C-1 | 4 | 96906 | MS35842-16 | C-1 | 17 |
| 81361 | E5-19-6641-74 | C-1 | 6 | 96906 | MS35842-16 | C-4 | 8 |
| 81361 | E5-19-6686 | C-8 | 5 | 96906 | MS35842-16 | C-5 | 4 |
| 81361 | E5-19-6699 | C-3 | 1 | 96906 | MS35842-16 | C-8 | 17 |
| 81361 | E5-19-6699-6 | C-3 | 9 | 96906 | MS51849-53 | C-1 | 22 |
| 81361 | E5-19-6699-7 | C-3 | 8 | 96906 | MS51849-55 | C-1 | 11 |
| 30327 | KF03-02PS | C-1 | 7 | 96906 | MS51849-55 | C-4 | 2 |
| 30327 | KF03-04RV | C-1 | 5 | 96906 | MS51849-55 | C-5 | 11 |
| 79919 | K35B1 | C-2 | 1 | 96906 | MS51849-56 | C-5 | 13 |
| 96906 | MS21044N08 | C-1 | 18 | 96906 | MS51849-64 | C-4 | 29 |
| 96906 | MS21044N08 | C-4 | 9 | 96906 | MS51849-66 | C-1 | 2 |
| 96906 | MS21044N08 | C-5 | 5 | 96906 | MS90727-33 | C-4 | 34 |
| 96906 | MS21044N3 | C-4 | 17 | 96906 | MS90727-6 | C-4 | 12 |
| 96906 | MS21044N5 | C-8 | 6 | 96906 | MS90727-64 | C-4 | 23 |
| 96906 | MS24679-2 | C-1 | 27 | 96906 | MS9352-06 | C-4 | 30 |
| 96906 | MS25041-8 | C-2 | 3 | 81349 | M15098/11-001 | C-6 | 1 |
| 96906 | MS25041-8 | C-7 | 3 | 80205 | MS1096-3-12 | C-4 | 13 |
| 96906 | MS25235-R311 | C-2 | 6 | 81361 | PL5-19-6707-13 | C-8 | 7 |
| 96906 | MS25237-387 | C-2 | 2 | 07137 | PTL-A1(3-C7A) | C-6 | 2 |
| 96906 | MS25237-387 | C-7 | 1 | 30327 | 261P1-4 | C-4 | 31 |
| 96906 | MS25358-4 | C-2 | 8 | 30327 | 261P1-4 | C-6 | 4 |
| 96906 | MS25358-5 | C-2 | 9 | 01126 | 41-601 | C-2 | 4 |
| 96906 | MS25358-6 | C-2 | 7 | 04426 | 44-601 | C-7 | 2 |
| 96906 | MS27183-10 | C-4 | 11 | 30327 | 44P GREEN | BULK | |
| 96906 | MS27183-12 | C-4 | 33 | 30327 | 44P RED | BULK | |
| 96906 | MS27183-12 | C-8 | 12 | 81361 | 5-19-6170-10 | C-8 | 16 |
| 96906 | MS27183-14 | C-4 | 21 | 81361 | 5-19-6348 | C-4 | 16 |
| 96906 | MS27183-14 | C-8 | 8 | 81361 | 5-19-6557 | C-1 | 9 |
| 96906 | MS27183-41 | C-1 | 12 | 81361 | 5-19-6718 | C-3 | 4 |

LENS ONLY
LENS ONLY

LENS ONLY


APPENDIX D EXPENDABLE SUPPLIES AND MATERIALS LIST

Section I INTRODUCTION

- D-1. SCOPE.** This appendix lists expendable supplies and materials you will need to operate and maintain the collective protection equipment. These items are authorized to you by CTA 50-970, Expendable Items (Except Medical, Class V, Repair Parts and Heraldic Items).
- D-2. EXPLANATION OF COLUMNS.**
- a. *Column 1 - Item Number.* This number is assigned to the entry in the listing and is referenced in the narrative instructions to identify the material (e.g. "Use dry-cleaning solvent, item 2, app D").
 - b. *Column 2 - Level.* This column identifies the lowest level of maintenance that requires the listed item.
O - Organizational Maintenance
F - Direct Support Maintenance
 - c. *Column 3 - National Stock Number.* This is the National stock number assigned to the item, use it to request or requisition the item.
 - d. *Column 4 - Description.* Indicates the Federal item name and, if required, a description to identify the part number followed by the Federal Supply Code for Manufacturer (FSCM) in parentheses, if applicable.
 - e. *Column 5 - Unit of Measure (U M).* Indicates the measure used in performing the actual maintenance function. This measure is expressed by a two-character alphabetical abbreviation (e.g., ea, in., pr). If the unit of measure differs from the unit of issue, requisition the lowest unit of issue that will satisfy your requirements.

Section II EXPENDABLE SUPPLIES AND MATERIALS LIST

| (1) ITEM NUMBER | (2) LEVEL | (3) NATIONAL STOCK NUMBER | (4) DESCRIPTION | (5) U M |
|--------------------|--------------|---------------------------------|--|------------|
| 1 | 0 | 8040-00-165-8614 | ADHESIVE, BONDING VULCANIZED. MMM-A-121 (81318) 1 qt can | QT |
| 2 | 0 | 8010-01-055-2319 | ALIPHATIC POLYURETHANE COATING: low reflective, chemical agent resistant MIL-C-16168 (MR) 1 gal cntnr | EA |
| 3 | 0 | 7920-00-514-2417 | BRUSH, ACID SWABBING horsehair bristle, 5 750 length HB643 | EA |



- NOTES:
- 1. FABRICATE FROM NSN
4720-00-065-8682 STOCK.
 - 2. ALL DIMENSIONS ARE IN INCHES.

| | LENGTH |
|---|--------|
| A | 12 |
| B | 22 |

Figure E-3. Rubber hose

ALPHABETICAL INDEX

| Subject | Page | Subject | Page |
|-----------------------------------|------|----------------------------------|------|
| A | | G | |
| Air duct Hose | 2-96 | Gas-Particulate Filter | |
| Airflow Valve | 2-76 | Unit, M59 | 2-62 |
| Installation | 2-78 | Green Tubing (Nonmetallic), | |
| Removal | 2-76 | Installation | 2-64 |
| Repair | 2-76 | Removal | 2-63 |
| G | | Housing Unit | 2-66 |
| Checks and Services, | | Identification Plate, | |
| Preventive Maintenance | 2-1 | Installation | 2-65 |
| Common Tools and Equipment | 2-1 | Removal | 2-65 |
| Compartment Control Module, | 2-81 | Instruction Plates, Housing Unit | |
| Installation | 2-81 | Installation | 2-66 |
| Removal | 2-81 | Removal | 2-66 |
| Lamps, | | Painting | 2-65 |
| Installation | 2-82 | Red Tubing (Nonmetallic), | |
| Removal | 2-82 | Installation | 2-64 |
| D | | Removal | 2-63 |
| Data, Equipment | 1-6 | H | |
| Description of Major | | Hoses, Airduct | |
| Components, Location and | 1-2 | Installation | 2-97 |
| Destruction of Materiel to | | Removal | 2-96 |
| Prevent Enemy Use | 1-1 | Replace/Repair | 2-97 |
| E | | Housing Unit, | 2-66 |
| Enemy Use, Destruction of | | Dust and Moisture Seal | |
| Materiel to Prevent | 1-1 | Protective Cap, | |
| Equipment Characteristics, | | Disassembly | 2-71 |
| Capabilities and Features | 1-2 | Installation | 2-72 |
| Equipment Data | 1-6 | Reassembly | 2-72 |
| Equipment Improvement | | Removal | 2-71 |
| Recommendations (EIR), | | Gas and Particulate Filters, | |
| Reporting | 1-1 | Installation | 2-70 |
| Expendable Supplies and | | Removal | 2-68 |
| Materials List | D-1 | Instruction Plates, | |
| F | | Installation | 2-66 |
| Functional Testing | 2-3 | Removal | 2-66 |
| | | Particulate Filters, | |
| | | Installation | 2-67 |
| | | Removal | 2-6 |
| | | Seals, | |
| | | Replacement | 2-6 |

| Subject | Page |
|-----------------------------------|------|
| I | |
| Identification Plate, Filter Unit | |
| Installation | 2-65 |
| Removal | 2-65 |
| Instruction Plates, Housing Unit | |
| Installation | 2-66 |
| Removal | 2-66 |
| Identification, Instruction, and | |
| Warning Plates | 1-4 |
| Illustrated List of Manufactured | |
| Items | E-1 |
| L | |
| Location and Description of | |
| Major Components | 1-2 |
| M | |
| Main Fan, | |
| Installation | 2-74 |
| Removal | 2-73 |
| Maintenance Allocation Chart | B-1 |
| Maintenance Forms and | |
| Records | 1-1 |
| Maintenance Instructions | 2-1 |
| Airduct Hoses | 2-96 |
| Airflow Valve | 2-76 |
| Cable W90 | 2-92 |
| Cable W91 | 2-90 |
| Cable C5-19-6162-20 | 2-84 |
| Cable C5-19-6170-10 | 2-87 |
| Cable C5-19-6712 | 2-94 |
| Compartment Control Module | 2-81 |
| Gas-Particulate Filter | |
| Unit, M59 | 2-62 |
| Hoses, Airduct | 2-96 |
| Main Fan | 2-73 |
| Power Distribution Unit | 2-79 |
| Protective Entrance | |
| Control Module | 2-57 |
| Protective Entrance, M14 | 2-50 |

| Subject | Page |
|----------------------------------|------|
| O | |
| Operation, Principles of | 1-8 |
| P | |
| Power Distribution Unit | |
| Installation | 2-79 |
| Removal | 2-79 |
| Identification Plate, | |
| Installation | 2-80 |
| Removal | 2-80 |
| 208V Lamp, | |
| Installation | 2-80 |
| Removal | 2-80 |
| Preparation for Storage or | |
| Shipment | 1-1 |
| Preventive Maintenance Checks | |
| and Services | 2-1 |
| Principles of Operation | 1-8 |
| Procedures, Troubleshooting | 2-10 |
| Protective Entrance Control | |
| Module | |
| Installation | 2-58 |
| Removal | 2-57 |
| Repair | 2-58 |
| Protective Entrance, M14 | |
| Dust and Moisture Seal | |
| Protective Cap, | |
| Disassembly | 2-54 |
| Installation | 2-55 |
| Reassembly | 2-54 |
| Removal | 2-53 |
| Repair | 2-54 |
| Impermeable Wall Fabric, | |
| Repair | 2-50 |
| Instruction Plates and | |
| Identification Plate, | |
| Installation | 2-52 |
| Removal | 2-51 |
| Painting | 2-56 |
| Static Port Adapter, | |
| Installation | 2-56 |
| Removal | 2-56 |
| Replace | 2-50 |
| Purpose of Equipment | 1-1 |

| Subject | Page |
|---------|------|
|---------|------|

R

| | |
|--|-----|
| References | A-1 |
| Repair Parts | C-1 |
| Repair Parts List | C-6 |
| Reporting Equipment Improvement Recommendations (EIR) | 1-1 |

S

| | |
|---|-----|
| Special Tools, TMDE, and Support Equipment | 2-1 |
|---|-----|

| Subject | Page |
|---------|------|
|---------|------|

T

| | |
|--|------|
| Tools and Equipment, Common | 2-1 |
| Tools, TMDE, and Support Equipment, Special | 2-1 |
| Troubleshooting Procedures | 2-10 |
| Type of Manual | 1-1 |

SOMETHING WRONG WITH THIS PUBLICATION?



THEN JOT DOWN THE
DOPE ABOUT IT ON THIS
FORM, CAREFULLY TEAR
IT OUT, FOLD IT AND DROP
IT IN THE MAIL

FROM (PRINT YOUR UNIT'S COMPLETE ADDRESS)

Your mailing address

DATE SENT

Date you fill out this form

PUBLICATION NUMBER

TM 3-4240-285-20&P

PUBLICATION DATE

PUBLICATION TITLE

COLLECTIVE PROTECTION EQUIPMENT,
GUIDED MISSILE SYSTEM, PATRIOT

BE EXACT PIN-POINT WHERE IT IS

IN THIS SPACE TELL WHAT IS WRONG
AND WHAT SHOULD BE DONE ABOUT IT.PAGE
NOPARA-
GRAPHFIGURE
NOTABLE
NO

1-1

1-4

ITEM 1. LINE 12. Change "Rock Island, IL 61201" to
read, "Aberdeen Proving Ground, MD 21010."

REASON: Wrong address.

2-28

2-12

ITEM 2. Test equipment. Add, "28V dc power
supply capable of delivery 2 amps"

REASON: Incomplete information.

2-43

2-14

ITEM 3. Add callout "20" to the shaft
slinger in the illustration.

REASON: Callout missing from illustration.

SAMPLE

PRINTED NAME GRADE OR TITLE AND TELEPHONE NUMBER

JOHN SMITH, S SGT

793-XXXX

SIGN HERE

John Smith

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS

SOMETHING WRONG WITH THIS PUBLICATION?



THEN ..JOT DOWN THE
DOPE ABOUT IT ON THIS
FORM. CAREFULLY TEAR
IT OUT. FOLD IT AND DROP
IT IN THE MAIL!

FROM (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER

TM 3-4240-286-20&P

PUBLICATION DATE

30 Nov 82

PUBLICATION TITLE

COLLECTIVE PROTECTION EQUIPMENT,
GUIDED MISSILE SYSTEM, PATRIOT

BE EXACT PIN-POINT WHERE IT IS

PAGE
NO

PARA-
GRAPH

FIGURE
NO

TABLE
NO

IN THIS SPACE TELL WHAT IS WRONG
AND WHAT SHOULD BE DONE ABOUT IT:

PRINTED NAME, GRADE OR TITLE AND TELEPHONE NUMBER

SIGN HERE

DA FORM 1 JUL 79 2028-2

PREVIOUS EDITIONS
ARE OBSOLETE

P S IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR
RECOMMENDATION MAKE A CARBON COPY OF THIS
AND GIVE IT TO YOUR HEADQUARTERS

TEAR ALONG DOTTED LINE

FILL IN YOUR
UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

POSTAGE AND FEES PAID
DEPARTMENT OF THE ARMY
DOD-314



OFFICIAL BUSINESS
PENALTY FOR PRIVATE USE \$300

Commander
US Army Armament Materiel Readiness Command
ATTN. DRSAR-MAS-C
Aberdeen Proving Ground, MD 21010

TEAR ALONG DOTTED LINE

By Order of the Secretary of the Army:

E. C. MEYER
General, United States Army
Chief of Staff

Official:

ROBERT M. JOYCE
Major General, United States Army
The Adjutant General

DISTRIBUTION:

To be distributed in accordance with DA Form 12-28 Organizational maintenance requirements for Field and Shelters.